

Spring release kit in Magnum low voltage circuit breakers

⚠ WARNING

- (1) ONLY QUALIFIED ELECTRICAL PERSONNEL SHOULD BE PERMITTED TO WORK ON THE EQUIPMENT
- (2) ALWAYS DE-ENERGIZE PRIMARY AND SECONDARY CIRCUITS IF A CIRCUIT BREAKER CANNOT BE REMOVED TO A SAFE WORK LOCATION
- (3) DRAWOUT CIRCUIT BREAKERS SHOULD BE LEVERED (RACKED) OUT TO THE DISCONNECT POSITION.
- (4) ALL CIRCUIT BREAKERS SHOULD BE SWITCHED TO THE OFF POSITION AND MECHANISM SPRINGS DISCHARGED.

FAILURE TO FOLLOW THESE STEPS FOR ALL PROCEDURES DESCRIBED IN THIS INSTRUCTION LEAFLET COULD RESULT IN DEATH, BODILY INJURY, OR PROPERTY DAMAGE.

⚠ WARNING

THE INSTRUCTIONS CONTAINED IN THIS IL AND ON PRODUCT LABELS MUST BE FOLLOWED. OBSERVE THE FIVE SAFETY RULES.

- DISCONNECTING;
- ENSURE THAT DEVICES CANNOT BE ACCIDENTALLY RESTARTED;
- VERIFY ISOLATION FROM THE SUPPLY;
- EARTHING AND SHORT-CIRCUITING; AND;
- COVERING OR PROVIDING BARRIERS TO ADJACENT LIVE PARTS.

Section 1: General information

The spring release (SR) (closing coil) remotely closes the circuit breaker when the coil is energized by a voltage input. When the spring release is used in conjunction with a latch check switch, the closing spring must be fully charged and the trip latch reset (not held in the tripped position) for the spring release to operate. If these conditions are not met, the close signal will be ignored until it is removed and re-applied.

This product is intended for use in Magnum circuit breakers with PXR or Digitrip trip units.

Note: All images show a Magnum circuit breaker with a PXR trip unit unless stated otherwise. Some components, such as the trip unit, not shown for clarity.

Required tools

- 1/4-inch drive socket
- 10 mm socket

Section 2: Installation of spring release

To install the spring release, proceed with the following steps:

Step 1: Remove the front cover by unscrewing the hex-head captive bolts (four for three-pole, six for four-pole) that join the cover to the breaker housing using a 10 mm 1/4-inch drive socket. Then hold the charge handle down approximately 45 degrees to pull off the cover.




Figure 1. Step 1.

EATON

Powering Business Worldwide

Step 2: Slide the lock on the spring release assembly to the unlocked (up) position. Install the hook feet down through openings as shown. Then slide the spring release forward towards the rear of the breaker so the feet engage the mounting plate. Slide the lock down into the locked position.






Figure 2. Step 2.

CAUTION

BECOME FAMILIAR WITH THIS CAUTION ON POLARITY BEFORE PROCEEDING WITH STEPS 3 OR 4. FAILURE TO APPLY THE CORRECT POLARITY WILL RESULT IN DAMAGE TO THE DEVICE.



When connecting a 24 Vdc or 48 Vdc Spring Release Device, be certain to apply positive (+) voltage to the secondary terminal in accordance with Table 1.



For a breaker with a Digitrip 1150 trip unit and a 24 Vdc or 48 Vdc Spring Release Device, be certain to apply positive voltage to secondary terminal "A13" for INCOM Close

Step 3: If the breaker has an 1150 trip unit, skip this step and proceed directly to Step 4. Otherwise, connect wires from the spring release to the secondary connector, referring to **Table 1**, in keeping with the wire markings. Terminal maps for the secondary connectors are located on top of the secondary connectors.

Table 1. Secondary connector spring release positions

Trip unit	Positive	Negative
Digitrip (Fig.3)	B12	B13
PXR (Fig. 4)	C52	C53




Figure 3. Step 3 Magnum with Digitrip.




Figure 4. Step 3 Magnum with PXR.

Step 4: For a breaker with a Digitrip 1150 trip unit only, find the rust colored connector in the vicinity of where the spring release device is mounted. This two-piece connector will easily separate by pulling apart on the two ends. Insert the spring release wire marked "B12" into the connector until it snaps into place. Re-connect the rust-colored connector. Insert the spring release wire "B13" into the breaker connector "B" at position 13.




Figure 5. Step 4.

Step 5: Reinstall front cover removed in Step 1.

Disclaimer of warranties and limitation of liability

The information, recommendations, descriptions, and safety notations in this document are based on Eaton Corporation's ("Eaton") experience and judgment, and may not cover all contingencies. If further information is required, an Eaton sales office should be consulted.

Sale of the product shown in this literature is subject to the terms and conditions outlined in appropriate Eaton selling policies or other contractual agreement between Eaton and the purchaser.

THERE ARE NO UNDERSTANDINGS, AGREEMENTS, WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, OTHER THAN THOSE SPECIFICALLY SET OUT IN ANY EXISTING CONTRACT BETWEEN THE PARTIES. ANY SUCH CONTRACT STATES THE ENTIRE OBLIGATION OF EATON. THE CONTENTS OF THIS DOCUMENT SHALL NOT BECOME PART OF OR MODIFY ANY CONTRACT BETWEEN THE PARTIES.

In no event will Eaton be responsible to the purchaser or user in contract, in tort (including negligence), strict liability, or otherwise for any special, indirect, incidental, or consequential damage or loss whatsoever, including but not limited to damage or loss of use of equipment, plant or power system, cost of capital, loss of power, additional expenses in the use of existing power facilities, or claims against the purchaser or user by its customers resulting from the use of the information, recommendations, and descriptions contained herein.

The information contained in this manual is subject to change without notice.

Eaton
1000 Eaton Boulevard
Cleveland, OH 44122
United States
Eaton.com

© 2021 Eaton
All Rights Reserved
Printed in USA
Publication No. IL2C14761H07/TBG 001548
December 2021