

Shunt trip in Magnum low voltage circuit breakers

⚠ WARNING

- (1) ONLY QUALIFIED ELECTRICAL PERSONNEL SHOULD BE PERMITTED TO WORK ON THE EQUIPMENT
- (2) ALWAYS DE-ENERGIZE PRIMARY AND SECONDARY CIRCUITS IF A CIRCUIT BREAKER CANNOT BE REMOVED TO A SAFE WORK LOCATION
- (3) DRAWOUT CIRCUIT BREAKERS SHOULD BE LEVERED (RACKED) OUT TO THE DISCONNECT POSITION.
- (4) ALL CIRCUIT BREAKERS SHOULD BE SWITCHED TO THE OFF POSITION AND MECHANISM SPRINGS DISCHARGED.

FAILURE TO FOLLOW THESE STEPS FOR ALL PROCEDURES DESCRIBED IN THIS INSTRUCTION LEAFLET COULD RESULT IN DEATH, BODILY INJURY, OR PROPERTY DAMAGE.

⚠ WARNING

THE INSTRUCTIONS CONTAINED IN THIS IL AND ON PRODUCT LABELS MUST BE FOLLOWED. OBSERVE THE FIVE SAFETY RULES.

- DISCONNECTING;
- ENSURE THAT DEVICES CANNOT BE ACCIDENTALLY RESTARTED;
- VERIFY ISOLATION FROM THE SUPPLY;
- EARTHING AND SHORT-CIRCUITING; AND;
- COVERING OR PROVIDING BARRIERS TO ADJACENT LIVE PARTS.

Section 1: General information

The shunt trip opens the circuit breaker when its coil is energized by a voltage input. The intermittent shunt trip is limited to intermittent duty and requires the included shunt trip cut-off switch. When replacing a standard shunt trip, both the shunt trip and the cut-off switch must be replaced. The continuous duty shunt trip does not require a switch.

This product is intended for use in Magnum circuit breakers with PXR or Digtrip trip units.

Note: All images show a Magnum circuit breaker with a PXR trip unit unless stated otherwise. Some components, such as the trip unit, not shown for clarity.

Required tools

- 1/4-inch drive socket
- 10 mm socket

Section 2: Installation of shunt trip

To install the shunt trip, proceed with the following steps:

Step 1: Remove the front cover by unscrewing the hex-head captive bolts (four for three-pole, six for four-pole) that join the cover to the breaker housing using a 10 mm 1/4-inch drive socket. Then hold the charge handle down approximately 45 degrees to pull off the cover.




Figure 1. Step 1.

EATON

Powering Business Worldwide

Step 2: The intermittent duty shunt trip comes with a cut-off switch. Mount the switch by sliding the lock to the unlocked (up) position. Install the hook feet down through the openings as shown. Then slide the assembly forward towards the left side of the breaker so the hook feet engage the mounting plate. Slide the lock down into the locked position.

Note: The cut-off switch is not applicable for the continuous duty shunt trip.




Figure 2. Step 2.

Step 3: Slide the lock on the shunt trip to the unlocked (up) position, and install the hook feet down through the opening. Then slide it forward until the feet engage the mounting plate. Slide the lock back down to lock the shunt trip in place.




Figure 3. Step 3.

Step 4: Mate the shunt trip connector with the cut off switch connector, where required.




Figure 4. Step 4.

Step 5: Connect wires from the shunt trip to the secondary connector referring to **Table 1**, in keeping with the wire markings. Terminal maps for the secondary connectors are located on top of the secondary connectors.

Table 1. Secondary connector shunt trip positions

Trip unit	Shunt trip 1		Shunt trip 2	
	Positive	Negative	Positive	Negative
Digitrip (Fig. 5)	B10	B11	A7	A8
PXR (Fig. 6)	C50	C51	C56	C57




Figure 5. Step 5 Magnum with Digitrip.




Figure 6. Step 5 Magnum with PXR.

Step 6: If a second shunt trip is to be installed, repeat Steps 2, 3, and 4 and wire to the secondary connector in accordance with Table 1.

Note: The second shunt trip in a Magnum circuit breaker with a PXR trip unit must be a continuous duty shunt trip.




Figure 7. Step 6.

Step 7: Reinstall front cover removed in Step 1.

Disclaimer of warranties and limitation of liability

The information, recommendations, descriptions, and safety notations in this document are based on Eaton Corporation's ("Eaton") experience and judgment, and may not cover all contingencies. If further information is required, an Eaton sales office should be consulted.

Sale of the product shown in this literature is subject to the terms and conditions outlined in appropriate Eaton selling policies or other contractual agreement between Eaton and the purchaser.

THERE ARE NO UNDERSTANDINGS, AGREEMENTS, WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, OTHER THAN THOSE SPECIFICALLY SET OUT IN ANY EXISTING CONTRACT BETWEEN THE PARTIES. ANY SUCH CONTRACT STATES THE ENTIRE OBLIGATION OF EATON. THE CONTENTS OF THIS DOCUMENT SHALL NOT BECOME PART OF OR MODIFY ANY CONTRACT BETWEEN THE PARTIES.

In no event will Eaton be responsible to the purchaser or user in contract, in tort (including negligence), strict liability, or otherwise for any special, indirect, incidental, or consequential damage or loss whatsoever, including but not limited to damage or loss of use of equipment, plant or power system, cost of capital, loss of power, additional expenses in the use of existing power facilities, or claims against the purchaser or user by its customers resulting from the use of the information, recommendations, and descriptions contained herein.

The information contained in this manual is subject to change without notice.

Eaton
1000 Eaton Boulevard
Cleveland, OH 44122
United States
Eaton.com

© 2021 Eaton
All Rights Reserved
Printed in USA
Publication No. IL2C14762H07/TBG 001549
December 2021