

## Maximum value.

# Faster lead times and flexible applications for any OEM solution.

In the oil and gas industry, you need every advantage you can get to operate efficiently and safely in harsh and hazardous areas.

You need products and solutions that solve real world problems.

Eaton's Crouse-Hinds Series EIC combination starters are a value series, easy to use and always available solution for panel shops, skid builders and other OEM applications.



#### **Application**

Harsh and hazardous motor control environments, including refineries, chemical and petrochemical plants, corrosive process facilities, food and beverage, marine and mining.

Across-the-line starting and stopping of polyphase AC induction motors with overload protection.



#### Certifications

#### **NEC and CEC:**

- Class I, Division 1 & 2, Groups B, C, D
- Class II, Division 1 & 2, Groups E, F, G
- Class III
- UL Standard 1203
- cUL to CSA C22.2 No. 30, No. 25
- NEMA 3, 3R, 4, 4X, 7BCD, 9EFG
- -20°C ≤ Ta ≤ +60°C

#### IECEx:

- Ex db IIB+H2 Gb
- Ex tb III C Db IP66
- -20°C ≤ Ta ≤ +60°C
- IECEx ETL 13.0022U

#### ATEX:

- II 2 G D Ex db IIB+H2 Gb
- Ex tb IIIC Db IP66
- -20°C ≤ Ta ≤ +60°C
- ITS13ATEX17813U certified

#### Materials

- Body, cover and handle copper-free aluminum
- Gasket neoprene
- Cover bolts and hinges stainless steel

## Why EIC combination starters?

#### **Engineered for OEMs**


- Two nameplates for easy identification and on site customizing
- Factory drilled and tapped field-removable mounting plate
- · Fast lead times
- · Globally certified operators

#### Multiple designs and options

- Available unpopulated for maximum design flexibility and fast lead times
- Populated versions built to order and shipped fast
- Three enclosure sizes with four operator positions
- Five combination starter sizes
- Factory wiring from breaker to starter provided for populated units



Enclosure: Size A NEMA starter size: 0-2



Enclosure: Size B NEMA starter size: 3



Enclosure: Size C NEMA starter size: 4







#### Field flexibility

- Factory-machined drilled and tapped entries up to three inches in diameter
- UL/cUL certified for field addition of drilled and tapped entries on sides, top, bottom or back of the enclosure
- Bolt-on/tap-in mounting feet allow for easy field replacement in case of damage or breaking
- ATEX/IECEx certified enclosure option for use in global applications




## **Ordering information**

#### Part number example #1 - populated

#### EICA-F2W4-J-070-RLN-GLF-PB23-S781

Fully populated EIC enclosure, size A, full voltage non-reversing Eaton starter, breaker with CPT, NEMA size 2, 480 VAC, heater with 70 Amp breaker, red LED "ON" pilot light and green LED "OFF" pilot light, start & stop pushbuttons, single auxiliary contact on starter



#### Enclosure size

Α	Used with NEMA sizes 0-2
В	Used with NEMA size 3
С	Used with NEMA size 4

<sup>\*</sup>Enclosure size is determined by the NEMA starter size. Refer to the NEMA size chart for the correct size starter, breaker/HMCP.




#### **Combination function**

F	non-reversing starter, 120V coil, breaker with CPT
	Full voltage,

Full voltage, non-reversing starter, breaker (no CPT)

Full voltage, non-reversing starter, 120V coil, HMCP with CPT

Full voltage,
non-reversing starter,
HMCP (no CPT)





0	NEMA size 0
1	NEMA size 1
2	NEMA size 2
3	NEMA size 3
4	NEMA size 4



#### Line voltage


1*	120 VAC
2	240 VAC
4	480 VAC
6	600 VAC

\*120 VAC option not available with F or H combination functions.

#### Part number example #2 - unpopulated

#### **EICA ATEX**

Unpopulated EIC enclosure, size A, ATEX rated





#### Enclosure size


Α	Used with NEMA sizes 0-2
В	Used with NEMA size 3
C	Head with NEMA size 4



#### Options

BLANK	NEC certified
ATEX	IECEx and ATEX certified
S752	External epoxy coating





<sup>\*</sup>Starter coil equals line voltage.

List operator designations in numerical order. Refer to the position chart below for reference.



# OR—

(3) and

RLN - GLF - PB23 - S78

#### Heater (FLA)

		NE	MA :	size
	FLA	0,1	2	3,4
BLANK	0.0 - 0.0	•	•	•
Α	0.8 - 1.3	•	•	
В	1.2 - 2.0	•	•	
С	1.8 - 2.9	•	•	
D	2.2 - 3.5	•	•	
E	3.2 - 5.2	•	•	
F	4.6 - 7.4	•	•	
G	6.8 - 11.0	•	•	
Н	9.1 - 14.0	•	•	
J	14.0 - 22.8	•	•	
L	23.5 - 38.5	•	•	
M	39.6 - 57.4		•	
N	53.9 - 74.9		•	
P	8.0 - 11.5			•
Q	11.4 - 15.7			•
R	14.3 - 19.0			•
S	18.0 - 24.5			•
Т	24.6 - 33.4			•
V	33.5 - 45.6			•
w	45.7 - 62.1			•
X	62.2 - 84.6			•
Υ	84.7 - 115.0			•
Z	106.0 - 144.0			•

Heater trip rating: Standard Trip – Class 20

#### Breaker\* HMCP\* Ope

015	15A	003	3A
020	20A	007	7A
025	25A	015	15A
030	30A	030	30A
035	35A	050	50A
040	40A	070	70A
045	45A	100	100A
050	50A	250	250A
060	60A	*Comb	ination
070	70A	function & K: 25	
080	80A	HMCP	can only
090	90A	be used NEMA	
			0.20

100A

110A

125A

150A

175A

starter

\*Combination functions F & G: Breakers 15-125A rated 600Y/347 VAC (480 VAC); 150-250A rated 600 VAC.

100

110

125

150\*\*

175\*\*

\*\*150A-200A can only be used with NEMA size 4 starter.

#### Operators\*

PB23	Start & Stop pushbutton with "START" & "STOP" legend plates (2 operator spaces)
RLN	Red LED 120V light w/ "ON" legend plate
GLF	Green LED 120V light w/ "OFF" legend plate
RLB	Red LED 120V pilot light w/ blank legend plate
GLB	Green LED 120V pilot light w/ blank legend plate
RR2	2-position selector switch with "ON - OFF" legend plate
RR3	3-position selector switch with HOA legend plate

\*Refer below for operator locations. Standard operator configurations shown.

Pilot lights and pushbuttons are not available when G or K combination functions are selected at 600 VAC line voltage.

#### Options\*

BST	Shunt trip 120V
ER	Electronic overload relay - Solid State (starter)
нт	Ambient compensated breaker (+50°C calibrated)
S214	External ground lug
S752	External epoxy coating
S756V	Breather & drain, Class 1, Groups B, C, D

#### Options - Space heater

Select one heater option only

R11	Space heater, 25 watts, 120V
R22	Space heater, 25 watts, 240V
R44	Space heater, 25 watts, 480V

#### **Options - Auxiliary contact**

Select one contact option only

S781	Auxiliary contact on starter 1NO & 1NC
S782	Auxiliary contact on starter 2NO & 2NC
S783	Auxiliary contact on starter 3NO & 3NC

#### Options - Auxiliary switch

Select one switch option only

S784	Auxiliary switch on circuit breaker, 1A&1B
S785	Auxiliary switches on circuit breaker, 2A &2 B
S786	8 point terminal block - 30A, 300V

\*List selected options in alphanumeric order. Only one option of each type allowed unless otherwise noted.

#### **Operator locations**



Size A



Size B



Size C

## **Electrical ratings**

#### **Electrical ratings – starter**

NEMA size	СРТ	Phase	Voltage	type
0-2	100VA	Single, 3		
3	200VA	3	120V, 240V, 480V or 600V	A600/P300
4	300VA	3	— 400V 01 000V	

<sup>\*</sup>No DC rating on starters. Standard configuration: 3 pole non-reversing starter, 3 pole on breaker and starter

#### Starter types by enclosure size

Enclosure size	Starter	EIC type	NEMA size
	Eaton Freedom AN16	Standard	
Α	Eaton Freedom AN19	ER option	0-2
	Eaton Space Savings AN13*	ATEX option	
	Eaton Freedom AN16	Standard	
В	Eaton Freedom AN19	ER option	3
	Eaton Space Savings AN13*	ATEX option	
	Eaton Freedom AN16	Standard	
С	Eaton Freedom AN19	ER opiton	4
	Eaton Space Savings AN13*	ATEX option	

<sup>\*</sup>Eaton Space Saving AN13 starter is the recommended ATEX starter and is not available as a factory installed option.

#### Maximum amperage - breaker/HMCP


Baton EG     70     125       Eaton HMCPE     50     100       Eaton F-Frame     70     225       Eaton HMCP     50     150       Eaton EG     125     125       Eaton HMCPE     100     100       Eaton F-Frame     125     225       Eaton HMCP     100     150       Eaton JG     200     250       Eaton HMCP     150     250	Enclosure size	Breaker/HMCP Type	Maximum amperage recommended (40°C ambient temp.)	Maximum amperage frame limit
Eaton F-Frame     70     225       Eaton HMCP     50     150       Eaton EG     125     125       Eaton HMCPE     100     100       Eaton F-Frame     125     225       Eaton HMCP     100     150       Eaton JG     200     250		Eaton EG	70	125
Eaton F-Frame     70     225       Eaton HMCP     50     150       Eaton EG     125     125       Eaton HMCPE     100     100       Eaton F-Frame     125     225       Eaton HMCP     100     150       Eaton JG     200     250	٨	Eaton HMCPE	50	100
Eaton EG 125 125  Eaton HMCPE 100 100  Eaton F-Frame 125 225  Eaton HMCP 100 150  Eaton JG 200 250	A	Eaton F-Frame	70	225
Eaton HMCPE         100         100           Eaton F-Frame         125         225           Eaton HMCP         100         150           Eaton JG         200         250		Eaton HMCP	50	150
Eaton F-Frame         125         225           Eaton HMCP         100         150           Eaton JG         200         250	В	Eaton EG	125	125
Eaton F-Frame       125       225         Eaton HMCP       100       150         Eaton JG       200       250		Eaton HMCPE	100	100
Eaton JG 200 250		Eaton F-Frame	125	225
		Eaton HMCP	100	150
Faton HMCP I 150 250	С	Eaton JG	200	250
Laton Hivor 3 130 230		Eaton HMCPJ	150	250
Eaton F-Frame 200 225		Eaton F-Frame	200	225
Eaton HMCP 150 150		Eaton HMCP	150	150

 $<sup>^*\</sup>mbox{Unpopulated EIC}$  engineered for use with any breaker/HMCP type listed above as per corresponding enclosure size.


## **Dimensions**


#### **Enclosure size A**


Size A	Α	В	С	D	E
inches	15.74	19.10	10.52	9.00	17.13
[mm]	[399.8]	[485.2]	[267.2]	[228.6]	[435.0]
















## **Dimensions**

### **Enclosure size B**



#### **Enclosure size C**

Size C	Α	В	С	D	E
inches	18.50	41.22	13.59	15.13	29.50
[mm]	[469.9]	[1047]	[345.1]	[384.3]	[749.3]



## U.S. (global headquarters): Eaton's Crouse-Hinds business

1201 Wolf Street Syracuse, NY 13208

(866) 764-5454 FAX: (315) 477-5179 FAX Orders Only: (866) 653-0640

crousecustomerctr@eaton.com

#### For more information:

If further assistance is required, please contact an authorized Eaton Distributor, Sales Office, or Customer Service Department.

#### Canada

Toll Free: 800-265-0502 FAX: (800) 263-9504 FAX Orders only: (866) 653-0645

#### Mexico/Latin America/Caribbean

52-555-804-4000 FAX: 52-555-804-4020

ventascentromex@eaton.com

#### **Europe (Germany)**

49 (0) 6271 806-500 49 (0) 6271 806-476 sales.CCH.de@ cooperindustries.com

#### **Eaton Middle East**

9714-8066100 FAX: 9714-8894813 chmesales@eaton.com

#### **Singapore**

65-6645-9888 FAX: 65-6297-4819 chsi-sales@ cooperindustries.com

#### China

86-21-2899-3600 FAX: 86-21-2899-4055 cchsales@ cooperindustries.com

#### Korea

82-2-3484-6783 82-2-3484-6778 CCHK-sales@ cooperindustries.com

#### Australia

61-2-8787-2777 FAX: 61-2-9609-2342 CEASales@ cooperindustries.com

#### India

91-124-4683888 FAX: 91-124-4683899 cchindia@eaton.com

#### Eaton

1000 Eaton Boulevard Cleveland, OH 44122 United States Eaton.com

© 2019 Eaton All Rights Reserved Printed in USA Publication No. 5396-0519 May 2019

Eaton is a registered trademark.

All other trademarks are property of their respective owners.