

Voltage Regulators

CL-6 Series Microprocessor-Based Regulator Control Cooper™ Control Interface 4.0 Users Guide

S225-11-2

Version 4.01





Figure 1.
CL-6A regulator control and Cooper™ Control Interface software *All Settings* screen.

Table of Contents

Safety Information	2
Introduction	4
Important User Information	5
What's In This Manual	5
Chapter 1: Getting Started	6
System Requirements	6
Installing CCI™ Software	7
Chapter 2: Using CCI Software	8
Start the CCI Software	8
Exit the CCI Software	9
How the CCI Software Works	9
Table of Contents (continued)	3



SAFETY FOR LIFE



Cooper Power Systems products meet or exceed all applicable industry standards relating to product safety. We actively promote safe practices in the use and maintenance of our products through our service literature, instructional training programs, and the continuous efforts of all Cooper Power Systems employees involved in product design, manufacture, marketing, and service.

We strongly urge that you always follow all locally approved safety procedures and safety instructions when working around high voltage lines and equipment and support our “Safety For Life” mission.

SAFETY INFORMATION

The instructions in this manual are not intended as a substitute for proper training or adequate experience in the safe operation of the equipment described. Only competent technicians who are familiar with this equipment should install, operate, and service it.

A competent technician has these qualifications:

- *Is thoroughly familiar with these instructions.*
- *Is trained in industry-accepted high- and low-voltage safe operating practices and procedures.*
- *Is trained and authorized to energize, de-energize, clear, and ground power distribution equipment.*
- *Is trained in the care and use of protective equipment such as flash clothing, safety glasses, face shield, hard hat, rubber gloves, hotstick, etc.*

Following is important safety information. For safe installation and operation of this equipment, be sure to read and understand all cautions and warnings.

Safety Instructions

Following are general caution and warning statements that apply to this equipment. Additional statements, related to specific tasks and procedures, are located throughout the manual.

⚠ DANGER: Hazardous voltage. Contact with hazardous voltage will cause death or severe personal injury. Follow all locally approved safety procedures when working around high- and low-voltage lines and equipment. G103.3

⚠ WARNING: Before installing, operating, maintaining, or testing this equipment, carefully read and understand the contents of this manual. Improper operation, handling or maintenance can result in death, severe personal injury, and equipment damage. G101.0

⚠ WARNING: This equipment is not intended to protect human life. Follow all locally approved procedures and safety practices when installing or operating this equipment. Failure to comply can result in death, severe personal injury and equipment damage. G102.1

⚠ WARNING: Power distribution equipment must be properly selected for the intended application. It must be installed and serviced by competent personnel who have been trained and understand proper safety procedures. These instructions are written for such personnel and are not a substitute for adequate training and experience in safety procedures. Failure to properly select, install, or maintain power distribution equipment can result in death, severe personal injury, and equipment damage. G122.2

Hazard Statement Definitions

This manual may contain four types of hazard statements:

⚠ DANGER: Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

⚠ WARNING: Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION: Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

⚠ CAUTION: Indicates a potentially hazardous situation which, if not avoided, may result in equipment damage only.



Table of Contents (continued from page 1)

Chapter 3: Working with a Control	10
Communicating with a CL-6A Control	10
Connecting to the CL-6A Control	10
Physical Connection	10
Initiate Communication	10
Quick Connect	11
Start Communications Icon	13
Operating the CL-6A Control	14
Operate	14
Reset Indicators	15
Chapter 4: Settings and Readings	16
Settings	16
Readings	17
Create New Settings	17
Receive Control Settings and Readings	18
Get Settings	18
Get Readings	18
Open Existing Settings or Readings Files	19
Reviewing Data and Changing Settings	20
Settings	20
Metering	25
Advanced Features	27
Maintenance	34
Saving Data on Your Computer	36
Saving Data on a Compact Flash Card	37
Deleting Data from Settings and Readings Files	37
Printing Reports	37
Chapter 5: Configuring the CCI Software	38
Configure Sessions	38
Configure Poller	39
Installation Directories	39
Chapter 6: Troubleshooting and Operating Tips	40
Cannot Communicate with a Control	40
Reports Will Not Print	40
Glossary	41
Baud Rate	41
Communications Port	41
Communications Protocol	41
Control ID	41
Control Type	41
Data Port	41
Demand Metering Date/Time Stamp	42
Reading	42
Settings	42

Introduction

The Cooper™ Control Interface program is a powerful, interactive Windows®-based tool to send and receive data from the CL-6A regulator control and to review readings and update settings while off-line from the Control. The CL-6A control supports customization of features to permit design and manufacture of customer-specific configuration and operating logic for voltage regulator applications.

Control parameters may be programmed, updated, and interrogated via personal computer using the CCI™ interface software. Temporary connection to the control is made through the front panel RS-232 port. Also, permanent connections, through optional Fiber-Optic/RS-232 or RS-485 interface boards, are available for SCADA or interconnections to other devices. It is possible to have multiple master stations communicating to a single control.

Other features include:

- Easy-to-use graphical interface screens with simple menus, scrolling lists of choices, and simple mouse-click selections.
- Settings created by modifying an existing file and saving it with a new name.
- Reports printed with common, file-appropriate applications without difficult printer and report configuration steps.
- Control maintenance: Field technicians can interact directly with controls; Engineers in an office can work with a copy of the settings and readings from a control.
- Settings for a new control built from scratch or from a copied and modified file, from another control, on a computer in the office. Copy the settings to a laptop computer to send to the control in the field.
- Standard configuration settings designed and used to set up new controls to ensure that similar controls will have similar setups.
- Readings and settings received into a laptop computer from a control in the field and then transferred to an engineering computer in the office for analysis and reporting. Look at saved readings and settings files to compare setups and results to help make engineering recommendations.
- Settings converted from one version to another version.
- The files, both settings and readings, are in a non-proprietary format (Microsoft® Excel) for easy use by other applications, such as spreadsheets and databases.



Important User Information

The CL-6A voltage regulator control offers the user the ability to apply it in a variety of applications, to program its operation over a wide range of parameters, and to customize its operating logic. Those responsible for the application of the CL-6A control must satisfy themselves that the programmed operating parameters have been tested to verify that they meet all performance and safety requirements, including any applicable regulations, codes, and standards.

Since there are many variables and user-selected operating characteristics associated with any particular installation, the user should take the necessary steps to ensure that the design, configuration, installation, and use of operating software are maintained in a secure and controlled manner by properly trained personnel.

What's In This Manual

This User Guide describes how to install and use the Cooper™ Control Interface (CCI™) program. It also describes how to configure the software to communicate with the CL-6A voltage regulator controls.

This manual is to be used in conjunction with the appropriate installation and operation instructions that were provided with the CL-6A voltage regulator control and the voltage regulator instructions:

- *Service Information S225-11-1 CL-6 Series Voltage Regulator Control Installation, Operation, and Maintenance Instructions*
- *Service Information S225-10-10 VR-32 Regulator and CL-5 Series Control Installation, Operation, and Maintenance Instructions and Parts Replacement Information*

This manual does not discuss how to use Windows® dialog boxes and menus, how to use the keyboard and mouse, or other computer operation functions. The manuals with your computer and the Microsoft® on-line help on the Windows® operating system can show you how to do these tasks.

The Cooper Control Interface program package includes the program, factory default settings, sample readings, support files, and this user guide.

Chapter 1: Getting Started

System Requirements

The recommended minimum software and hardware your computer system needs to run CCI successfully is:

- A computer with a minimum of an Intel® Pentium® 90 MHz processor: an Intel® Pentium® 200 MHz processor is recommended.
- A hard disk with 35 MB of free space.
- 32 MB of memory (RAM): 64 MB of RAM is recommended.
- One of the following operating systems:
Microsoft® Windows® 95, Windows® 98, Windows® 2000, Windows® XP, or Windows NT® (4.0 with Service Pack 3 or later).
This version of the software supports only 32-bit operating systems and is not compatible with Windows® 3.1.
- CCI installation software with program key code.
The installation program will ask you for this program key. You will find it on the label of your CD-ROM. You should write this key down before installing CCI so that you can provide it when it is requested.
- An available RS-232 serial port for connection to a control.
- A CD-ROM drive.
- A compact flash drive is recommended.
- A Windows® operating-system-compatible mouse or other pointing device.
- A Windows® operating-system-compatible printer to print reports.



Installing CCI Software

The installation CD contains a setup program that will guide you through the installation process. In most cases, you should accept the default answers it proposes for each question. You may want to change some of the options, but be sure to read the recommendations on each screen.

The installation CD may contain a "ReadMe.txt" file with new information that became available after this manual was printed. The installation program will ask if you want to view the file.

This installation uses standard Windows® operating system procedures.

1. Quit all running applications.
2. Insert the CD into the CD drive.

Note: The set-up program should start automatically and prompt for responses to proceed through the installation. If it does not appear, click the **Start** button and select **Run: Start > Run**. Type **d:/setup** in the **Run** box and click **OK**.

These instructions assume your CD drive is "D." If using a different CD drive, substitute the drive letter in place of "D."

3. Follow the instructions on the screen to complete the installation.
 - A. Accept licensing agreement.
 - B. Enter key code, which is printed on the software CD.
 - C. Select to add the program to the **Start** menu and/or as a desktop icon.

Note: The icon is a voltage regulator symbol labeled VTS.
 - D. Enter installation location



Note: The default is C:\Cooper\CCI4. It is recommended to install under **C:\Programs Files\Cooper Power Systems**.

Note: When installing on Windows® 95 or Windows® 98 operating systems, it is common that a file installation error may be encountered. If a file installation error is received, go the Microsoft® web site and check to find the current version of the file requested. For convenience, some of these files may be found in the Microsoft® upgrade directory on the installation CD.

If using a more current operating system than the Windows® 98 operating system and an installation error occurs, please contact a Cooper Power System representative for additional assistance.


Chapter 2: Using CCI Software

Start the CCI Software



1. To start the CCI program, when installed as recommended, click on the **Start** button and select **Start > Programs > Cooper Power Systems > VTS**, or double-click the icon (voltage regulator symbol, labeled VTS), on the desktop.
2. The program files are loaded and the initial screen appears. Click on the **CL6/5/4** button to start the CL-6 interface.
3. The CL-6 interface will start and a window opens that shows the progress and allows a cancel command. This window will close automatically when the parameter database is initialized, the GUI elements are loaded, the default settings are loaded, and the windows are initialized.
4. The CL-6 interface window will open. The toolbar will note that the PC and control are not communicating. The **Start Communications** icon (green traffic light) indicates that the CCI software is ready to begin the communication process.

CCI Interface Icons



Exit the CCI Software

The interface may be stopped by choosing **File > Exit** or clicking **Exit** icon (arrow pointing to a door) on the toolbar or the close-window button (**X**). This returns to the start window. Click the close-window button (**X**) to exit the program.

How the CCI Software Works

The CCI Software Interface is a custom interface developed upon the VTS™ platform. For additional information on the VTS™ platform, see www.trihedral.com.

This design allows the customer to purchase a developer's license if desired from Trihedral Engineering Limited and then modify the program as needed.

Chapter 3: Working with a Control

Communicating with a CL-6A Control

Connect a PC to a Control to receive settings and readings from it, to send new settings to it, and to operate it.

The *Communicate* drop-down menu accesses the following functions: Quick Connect, Sessions, Stop Comms, Obtain Readings, Obtain Settings, Send All Settings, and Send All Comm Settings.

The Cooper Control Interface software communicates with a control using either the 2179 or DNP3 protocols. See the **Quick Connect** section of this chapter and **Chapter 5: Configuring the CCI Software** for more information about configuring the software for communications.


Connecting to the CL-6A Control

Physical Connection

Connecting through the front data port: Connect to the front COM1 Data Port on the control with a straight-through 9-pin cable to the COM port on the PC.

Connecting to a communications port accessory on the back panel: Connect a serial cable with a null modem from the COM port on your PC to the serial connection of the control.

Initiate Communication



Select **Communicate > Quick Connect** to access the *Quick Connect* dialog box or click the **Start Communications** icon to access the *Start Communications* screen.

Note: The PC COM Port must be available for connection.

See the following **Quick Connect** and the **Start Communications Icon** sections.


Quick Connect

The *Quick Connect* dialog box has four clickable file tabs: *Connect*, *Port*, *DNP*, and *2179*. In any tab, click appropriate buttons to **Save** changes, **Restore Defaults**, **Connect** to the CL6 control, or **Close** the dialog box. The PC Port, Baud Rate, and Protocol fields are included in both the *Connect* and *Port* tabs.

Note: Changes are not saved until the **Save** button is clicked. Saving will add this setup to the session list.

When the communication parameters have been configured, click **Connect**; the *Start Communicating* box is opened. Select **OK** or **Cancel**: select **OK** to start communicating.

Connect



In the *Connect* tab, use the default settings or enter Session Name, Description, Control ID, Slave/RTU Address, and Master Address. Choose Control Type, PC Port, Baud Rate, and Protocol from drop-down menus. Also, click in check boxes to enable Control Type Must Match, ID Mismatch Warning, and Auto Correct; the default is enabled.

Session Name

The name assigned to the communication configuration or session.

Description

A more detailed text description of the communication configuration or session.

Control Type

CL-6A, CL-5E, or CL-5D.

Control ID

Field used to identify different controls.

PC Port

The physical number of the port on the computer.

Baud Rate

The baud rate at which the port on the computer is set to communicate.

Protocol

The protocol, DNP or 2179, in this communication configuration or session.


Slave/RTU Address

The address of the control that the software will communicate with in this communication configuration or session.

Master Address

The address of the software program.

Port



The *Port* tab allows detailed entry of port settings, including Data Bits, Parity, and Stop Bits. Also, click check boxes to enable Echo and Key Off Delay and to enter the Key Off Delay value.

Data Bits

The number of bits in a message. This parameter should be set to “8”.

Parity

This determines if the parity bit is used. This parameter should be set to “None.”

Stop Bits

This determines how many bits are used to signal the end of the message. This parameter should be set to “1.”


Echo

This will allow the software to receive an echo of the message that it sends when it is communicating to controls that are in a fiber-optic loop.

Key Off Delay

The amount of time the software will wait after receiving a message before sending a response, to avoid collisions.

DNP and 2179



The *DNP* and *2179* tabs allow entry of the Slave/RTU Address, Master Address, Retries, and the Timeout. Additionally, use the DNP tab to enable the Data Link Confirm feature.

Retries

The number of times that the software will resend a message if a response is not received from the control.

Timeout

The amount of time the software will wait for a response from the control before retrying the request.

Data Link Confirm

This determines if the software is anticipating a Data Link message from the control.

Start Communications Icon



Click the **Start Communications** icon (green traffic light) to open the *Start Communications* screen. Highlight the desired connection configuration.

Note: By default, the front port COM1 is set for use with the 2179 Protocol, a control address of 1, and a baud rate of 9600.

If no preconfigured connection configuration matches the settings of the COM port used on your computer and of the port on the control, use the *Quick Connect* or *Sessions* dialog box. Refer to **Chapter 5: Configuring the Software** to create a new configuration using the *Sessions* dialog box.

Click **Connect**; the *Start Communicating* box is opened. Select **OK** or **Cancel**: select **OK** to start communicating.

The toolbar displays COMMUNICATING when the connection is ready. Also, the Stop Communicating icon (red traffic light) is displayed.




Note: When the ID Mismatch Warning is enabled (default setting) and an unexpected control is identified, the software prompts user to continue or cancel: click **Continue** to begin communicating.

Operating the CL-6A Control



The *Operate* drop-down menu accesses the following functions: *Remote Tap* and *Demand Reset*. The following dialog boxes are available in the software for operating a control while communicating with the control.


Operate



Select **Operate > Remote Tap** to access the *Operate* dialog box. Use this dialog box to change the tap position and the blocking status. The dialog box also displays some of the instantaneous metering values that are available on the front panel of a control. This is available only while communicating with the control.

Note: Commands performed within this dialog box do not override control panel toggle-switch settings. The Control Function toggle switch must be set to Auto/Remote to allow operation from within the software.

Reset Indicators



In the *Reset Indicators* screen, click in a radio button to choose which items to reset. Select the **All** button to reset all of the indicators included in the screen. Individual indicators, such as TIME-ON-TAP, can also be selected. Click the **Reset** button to reset values. Reset is not available unless the program is communicating with a control.

Note: When you click a button, the program sends the command to the control immediately. It does not change the settings in the *file* on the PC. The *display screen* is updated when the control sends information to the PC.

Demand Metering and Tap Position

Resets all of the minimum and maximum values included in the *Demand Metering* screen for both forward and reverse values. Access this screen via the *Metering* menu.

KW hr and KQ hr

Resets the kW hr and kQ hr indicators included in the *Instantaneous Metering* screen. Access this screen via the *Metering* menu.

Period Operations Counters

Resets all counters except the total operations counter included in the *Operations Counters* screen. Access this screen via the *Metering* menu.

TIME-ON-TAP

Resets the TIME-ON-TAP indicators. Access this screen via the *Maintenance* menu.

Resynch Counters

Resets counters included in the *Mismatched Counters* screen. View the *Mismatched Counters* screen via **Maintenance > Control Diagnostics > Mismatched Counters**.

Chapter 4: Settings and Readings

Some screens in the program display only the informational part of a reading from a control to view the information, not change the data. Other screens display settings and allow changes. Settings for a control are stored as "settings" records in the computer database, and readings from the same control are saved as "readings" records. When working with data records stored on a computer, choose to open either settings or readings, depending on the use.

Settings

Settings are the control programming parameters that set up how the control operates. The CCI software lets you receive the settings from a control to review them, change them, or save them for later use. *Settings that are changed but not saved are displayed in blue.* The program also lets you create new settings and upload them to a control. A settings file on your computer can be transferred to another computer for review and modification. You can receive a settings file from someone else and upload it to a control attached to your PC.

Readings

A reading includes settings plus the output of metering and, if selected, the alarm, events, profile records, and Histograms of the control. The metering, load profile, and event/profile recorder data tell you how the system and device with which the control operates is performing. The program allows you to retrieve this data from a control so that it can be analyzed. You can view it on the screen, and the readings file can be sent to another computer for review.

Create New Settings

Build new settings for a new control by selecting **File > New Settings**. This opens the default file and DEFAULT displays in the toolbar settings file-reference area. Choose **Settings > All Settings** to view the actual settings.


Readings saved from the Cooper Control Interface v3.0 program can be selected. New settings can be based on settings and readings from the CCI v3.0 program.

See the **Reviewing and Changing Settings** section of this manual.

Receive Control Settings and Readings

Receive settings and readings while communicating with a control.

Get Settings:



The program does not get all the settings from the control by default as soon as the communications start. If the toolbar status shows NOT COMMUNICATING, start communications as described previously.

To view settings, select **Settings > All Settings** or open an individual feature's screen; click **Refresh**.

To get a settings file from the control, select **Communicate > Obtain Settings**. The *Obtain Settings* dialog box opens. Select the "Standard" radio button to select basic Configurable settings or select the "All" radio button to select all of the Configurable settings.

Click **Continue**; the *Obtain Settings* confirmation box is opened. Select **OK** to get the settings.

The settings can be saved as a compact flash file (.cfg) or an Excel file (.xls). To save these settings in a file on the PC, select **File > Save Settings As**, select or create a folder, and enter a Description. Click **Save**.

Get Readings:

Get a readings file from the control by selecting **Communicate > Obtain Reading from Control** or clicking on the **Obtain Reading from Control** button (camera graphic) on the toolbar.

Note: If not already communicating with the control, the program will open the *Start Communications* screen.


Click **Continue**; the *Obtain Readings* confirmation box is opened. Select **OK** to get the settings.

The readings can be saved as a data file (.dat) or an Excel file (.xls). Select **File > Save Readings As**, select or create a folder, and enter a Description. Click **Save**.

As soon as the reading is obtained, information can be viewed by selecting a dialog box from the appropriate drop-down menu.

Click **Refresh** on the toolbar to update the readings while communicating with the control.

Open Existing Settings or Readings Files



Open existing settings or readings, stored in files on a PC, in the CCI program. Choose **Open Settings** or **Open Readings** from the *File* menu or click the open readings or settings icon (opening folder graphics) on the tool bar. Choose the file that contains the data and then select the reading or settings file to view. The existing file used can be a readings file; the program will get only the settings.

Select **Settings > All Settings** to view the settings.

The settings opened from a file can be modified and saved or sent to a control. The opened file could be one saved during a communications session with a control or it could be from another computer.

Readings saved from CCI version 3.0 can be selected.

See the **Reviewing and Changing Settings** section of this manual.

Reviewing Data and Changing Settings

Display and change settings in dialog boxes accessed via the following drop-down menus: *Settings*, *Metering*, *Advanced*, and *Maintenance*.

For more information on how to interpret settings and readings, see *Service Information S225-11-1* and *Service Information S225-10-10*.

Settings



The *Settings* drop-down menu accesses the following functions: *All Settings*, *Basic Control Settings*, *Configuration*, *SOFT-ADD-AMP™*, *Voltage Limiter*, *Voltage Reduction*, *Security*, *Comm Ports*, *Send Changed Settings*, *Send All Settings*, *Send Changed Comm Settings*, *Send All Comm Settings*, and *Set Control Clock*.

Changing Settings when Connected to Control

Select **Settings > All Settings**. Highlight the value to be changed. Type in the new value and then tab out of that cell. After tabbing, the changed value displays in blue, indicating that it has been changed in the screen but not yet updated to the control. Select **Settings > Send Changed Settings** to update the control. The *Send Settings* confirmation box opens; click **OK** to send settings.


Click the **Refresh** button and the changed value will display in black.

Note: This does not save the existing or new settings file to the PC.

Changing Settings When Working with a Configuration File




Select **Settings > All Settings**. Highlight the value to be changed. Type in the new value and then tab out of that cell. After tabbing, the changed value displays in blue, indicating that it has been changed on the screen but not yet saved in a file. Select **File > Save Settings**. The software prompts for a description. Enter a description and click **Continue**. The changed value will display in black, indicating current file configurations.



The file can be saved as an Excel (.xls) or a compact flash (.cfg) file. The default is to save the file into the folder from which it was originally opened. Select **File > Save File As** to specify a file format or to save to another folder. When saving as a .cfg file, the software prompts for the control firmware version.

All Settings



The *All Settings* screen allows changing virtually all the configurable settings from within one screen.

To change a setting, highlight the value box and type in the new setting; then tab out of the box. The changed value is now displayed in blue, indicating that the value has been changed but not saved. The value is displayed in black after the change is saved.

Save values from this screen to a file using **File > Save Settings** or **File > Save Settings As**.

When communicating with a control, send the new settings values by clicking the **Send All** or **Send Changed** buttons.

Note: After the new settings are sent to the control, the values shown in the screen revert to the previous values. Click the **Poll** button to show the new values are in the control.

Basic Control Settings

The screenshot shows a dialog box titled "Basic Ctl Sett" with the following settings:

Forward	
Set Voltage	120.0
Bandwidth	3.0
Time Delay	20.0
LDC Resist	0.0
LDC React	0.0
Reverse Sensing Mode	
(0) Locked Forward	
Reverse Threshold	1.0
Reverse	
Set Voltage	120.0
Bandwidth	2.0
Time Delay	45.0
LDC Resist	0.0
LDC React	0.0

Set and view the basic voltage regulator operating parameters including forward and reverse values for set voltage, bandwidth, time delay, and line drop resistance and reactance. Also, change the Reverse Sensing Mode settings.


Configuration

The screenshot shows a dialog box titled "Configuration" with the following settings:

Identification	84
Configuration	(0) Wye (or Star)
Operating Mode	(0) Sequential (Std)
Sys Line Voltage	7200
PT Ratio	60.0
CT Rating	200
Demand Interval	15.0
Src Side Calc	(1) On
Regulator Type	(0) A
Load Tap Changer Type	(3) Cooper Spring Drive
Control Date	
Control Time	


Set and view control configuration data including the control identification, wiring configuration (Wye or Delta), control operating mode, and load tap-changer type. Also display, but not set, the date and time of a connected control. See **Control Clock** to set the date and time.

SOFT-ADD-AMP™




Set and view the parameters for the SOFT-ADD-AMP™ feature of the control.

Voltage Limiter



Set and view the voltage limiter mode and the high and low output voltage limits of the regulator.

Voltage Reduction



Set and view the regulator voltage reduction settings of the control.

Advanced Features



Turn selected advanced features on or off.


Security



View the control manual-access security codes (passwords).

Note: See the discussion of security codes in Service Information S225-11-1 before changing the Security Override code.

Comm Ports



Set and view the communications parameters for the control. This does not affect the PC. Only the values appropriate for the connected control are displayed.

Note: Changing communications settings while communicating with control may cause communications error.

Note: Settings from this dialog box are not included in *All Settings*.

Control Clock




Check and set the clock in a control. The current date/time in the control will be displayed.

Set the control clock to the PC's clock or a specified date/time.


Note: This function can be used only while communicating with a control.

Metering



The *Metering* drop-down menu accesses the following functions: *Instantaneous Metering*, *Demand Metering-Forward*, *Demand Metering-Reverse*, *Status*, *Calibration*, and *Operations Counters*.

Instantaneous Metering



Display instantaneous meter readings from the regulator sensors. Not available when an existing *settings* file has been opened.


Demand Metering – Forward

Demand Metering – Reverse



Display demand metering values from the control. See *Service Information S225-11-1* and *Service Information S225-10-10* for an explanation of the metering and reporting algorithms. Not available when an existing *settings* file has been opened.

Status




Display the status of the control functions. Not available when an existing *settings* file has been opened.

Calibration

Display the calibration values for the control. Not available when an existing *settings* file has been opened.

Operations Counters



Display the operations counters for the control. Not available when an existing *settings* file has been opened.


Advanced Features



The *Advanced* drop-down menu accesses the following features: *Histograms*, *Alarm Recorder*, *Event Recorder*, *Profile Data*, *2179 Configuration*, *DNP Configuration*, and *Programmable I/O*. Turn advanced features on or off in the *All Settings* screen. Perform specific configuration for advanced features in the appropriate screen. Commands for advanced features such as **Send**, **Read**, **Refresh**, and **Clear** are also performed in these screens, not via the Communicate, Setup, or Settings menus; however, the toolbar buttons can be used.


Note: Advanced Features data can be obtained from the CL-6 control for analysis on your PC via a flash card by using the data writer function, Function Code 350, to save the data to the card. The card can then be read from your PC.

Histograms



Select, Read, or Clear the available Histograms. Use the drop-down menu to select different readings for Histogram analysis.

Note: Histograms must be turned on in the *Settings > All Settings* dialog box for data to be gathered.




Configure

The Configure button opens a subwindow where the upper and lower limits for the Histograms may be read, modified, and sent.

	Low	High	
Forward Primary Load Current (A)	20	1000	Read All
Forward Secondary Load Voltage	114	126	
Forward Secondary Source Volt	114	126	Send All
Forward Compensated Voltage	114	126	
Forward Load KVA (KVA)	40	840	Help
Forward Load KW (KW)	40	840	
Forward Load KVAR (KVAR)	20	500	Cancel
Reverse Primary Load Current (A)	20	1000	
Reverse Secondary Load Voltage	114	126	
Reverse Secondary Source Volt	114	126	
Reverse Secondary Comp Voltage	114	126	
Reverse Load KVA (KVA)	40	840	
Reverse Load KW (KW)	40	840	
Reverse Load KVAR (KVAR)	20	500	
Percent Regulation (%)	-10	10	

Alarms




Read or Acknowledge the configured Alarms. Select the appropriate radio button to view Active, Inactive, or All Configured Alarms.

Note: Data Alarms and/or Status Alarms must be turned on in the *Settings > All Settings* dialog box for data to be gathered.



Click **Refresh** to obtain current readings. This opens the *Refresh Alarms* dialog box. Select which alarm readings to refresh; click **Continue** or **Cancel**.




Configure

The Configure button opens a subwindow where available status and data alarms can be added or removed from the configured alarms. Also, by highlighting a configured Alarm, the properties for this Alarm may be modified.

- Priority
The priority determines if the Alarm activates one of the LEDs on the front panel.


Priority Setting	Behavior
0-50	Alarm LED on when active
51-100	Warning LED on when active
101-127	LEDs are not controlled



- Alarm Delay (sec)
The number of seconds that the configured alarm condition must be true before the Alarm is made active.
- Alarm on Low
For Status Alarms, this inverts the behavior of the Alarm.
- Threshold
For Data Alarms, this is the value above (or below) which the Alarm becomes active.

A configured alarm can be set to record an event and/or a profile when the alarm is active or inactive.

Events




Read or Acknowledge the configured Events.


Configure

The Configure button opens a subwindow where available events can be added or removed from the configured events.

Note: The Event Recorder must be turned on in the *Settings > All Settings* dialog box for data to be gathered.




Data Profiler



Read, or Acknowledge the Data Profiler.

Note: The Data Profiler must be turned on in the *Settings > All Settings* dialog box for data to be gathered.




Configure

The Configure button opens a subwindow where available parameters can be added or removed from the selected profiler parameters. Also, the sampling behavior of the profiler may be modified.


- **Start Date**
The day when the Profiler will begin Sampling.
- **Stop Date**
The day when the Profiler will stop Sampling.
- **Start Time**
The time of day when the Profiler will begin Sampling (24-hour clock).
- **Duration**
The period of time beginning at the start time that the profiler will be active.
- **Interval**
The amount of time between profile samples.

2179 Configuration




Read or select the preconfigured 2179 protocol maps. Also, configure the 2179 User Ordinal Points Map.

User should have detailed knowledge of 2179 ordinal maps prior to modifying the user map.




DNP3 Configuration



Read or modify the DNP3 communications settings including the preconfigured DNP3 protocol maps. Also, configure the DNP3 User Data Dictionary.


User should have detailed knowledge of DNP data dictionaries prior to modifying the user map.



Programmable I/O

Read or modify the Programmable I/O configuration. When creating a Programmable I/O configuration, first enter a description and select the desired equation Output. Then select the Form Type of the equation. For the Form Type selected, complete the appropriate equation tabs. The equation tabs are where the inputs to the equation are entered.

For additional information on creating a Programmable I/O equation, please contact your Cooper Power Systems representative.




Maintenance



The *Maintenance* drop-down menu accesses the following features: *Time On Tap*, *Preventive Maintenance Tapping*, *Duty Cycle Monitor*, *Diagnostics*, and *CCI Diagnostics*.


TIME-ON-TAP™



Displays the amount of time that the voltage regulator tap-changer has been in a particular position. When communicating with the control, click **Read** to obtain data. This graphically displays the percent of time in each tap position since the last reset. The total amount of time since last reset is displayed below the graph. Click **Reset** to clear all values to zero and start the timer again.

Note: No data will be read until after the first tapping operation.

Preventive Maintenance Tapping (PMT™)




Set and view the PMT Preventive Maintenance Tapping parameters, including Mode A and Mode B.

The PMT feature is used to reduce coking. Coking can occur when the tap-changer remains in one tap position for an extended period of time.


Mode A, when enabled, will raise the tap-changer one position, lower two positions, and then raise one position, to exercise the contacts.

Mode B, when enabled, will raise or lower the tap-changer through neutral to exercise the contacts and the reversing switch.

Duty Cycle Monitor



View the Duty Cycle Monitor parameters including the worst-case contact life and the voltage regulator design type. When communicating with a control, click **Read** to view the percent of contact life consumed for each contact.




Configuration

This feature is configured at the factory. Contact Cooper Power Systems for DMC specifications. When communicating with a control, click **Read** to view the Duty Cycle Monitor parameters for that control.

Note: On new units, this is preset at the factory. Configure should only be used when placing a new control on an existing unit or after upgrading firmware.

Control Diagnostics



Mismatch Counters

Display the *Mismatch Counters* screen; reset the tap position resynchronization counters.

Note: After initial installation of the control, these counters should not increase. If tap position resynchronizations are occurring, check to make sure that the proper tap-changer has been selected. If the counters continue to increase, contact your Cooper Power Systems representative for additional assistance.

Firmware

The *Version Info* screen displays the firmware revision of the control.


Device Note

Display and modify the control device note.

Error Recorder

Display a log of control errors.

CCI Diagnostics



Comms View

Display the Communication Messages between the software and the control.

Comms Statistics

Display the statistics for the communication between the software and the control.


CCI Statistics

Display the VTS version and the memory used.

CCI Error Log

Display a log of the Software errors.

Saving Data on Your Computer



The interface program can contain settings and readings obtained from a control during communications, or it may contain settings from another file that may have been changed. You can save the data on the disk in a PC for later use. The program will save the data as settings or readings, depending on which type is in the program at the time.

1. If communicating with a control, obtain the readings or settings, then stop communications.
2. Select **File > Save** or click the Diskette button on the Tool bar. If you are not already working on a file that you opened with *Open Readings* or *Open Settings*, *Save* will behave like a *Save As* to allowing renaming the file when saving.
3. Select **File > Save As** to create a new file and supply a name for it.

Settings can be saved to an Excel (xls) file or a compact flash (.cfg) file. Readings can be saved to an Excel (xls) file or a data (.dat) file. When saving as a .cfg file, the software prompts for the control firmware version.

Saving Data on a Compact Flash Card

The interface program can contain settings and readings obtained from a control during communications, or it may contain settings from another file that may have been changed. You can save the data on the compact flash card for download into the control. The program will save the data as settings or readings, depending on which type is in the program at the time.

1. Select **File > Save** or click the Diskette button on the Tool bar. If you are not already working on a file that you opened with *Open Readings* or *Open Settings*, *Save* will behave like a *Save As* to allowing renaming the file when saving.
2. Select **File > Save As** to create a new file and supply a name for it.

Settings must be saved to a compact flash (.cfg) file to be read by the control from the compact flash card. The software prompts for the control firmware version.

The file must be named either “standard.cfg” or in the format “12345-001.cfg”, where “12345” is the regulator identification, to be read by the control. The regulator identification is found at function code 40 on the control.

Note: Refer to *Service Information S225-11-1 CL-6 Series Control Installation, Operation, and Maintenance Instructions*, Section 7:4, for more information.

Deleting Data from Settings and Readings Files

Readings and settings from the computer files can be selected and deleted when no longer needed. Other data in the same file will not be deleted.

Choose *Delete Readings* or *Delete Settings* from the *File* menu, and then select the file that contains the data to delete.

The program will list the readings or settings contained in the file selected. Choose one or more to delete.

Deleting data from a file does not affect the data currently in the program.

Deleting all readings or settings from a file does not delete the file itself. Delete the file by using the Windows® Explorer feature.


Printing Reports

To print reports, identify the format of file to be printed and open the appropriate application. Open the file to be printed with appropriate application and print.


Chapter 5: Configuring the Software

The *Setup* drop-down menu accesses the following communication features: *Session* and *Poller Setup*.

Configure Sessions




Select **Setup > Sessions** to access the *Configure Sessions* screen to view existing communication configurations



To view, configure, and delete communication configurations, click the **Properties** button. To configure a new communication configuration, click the **New** button. For more information on communication configuration, refer to the **Quick Connect** section of this manual.

Configure Poller



Select **Setup > Poller Setup** to access the *Poller Configure* screen. View and configure how the software polls the control. Click the **Apply** button to apply changes made in this screen.

If *Continuous* polling is selected for an item, the *Period* determines how often this poll will be performed. The *Delay* setting determines how much time the software should wait after connecting before beginning the continuous poll.

If *On At Startup* is selected, by clicking in the check box in the appropriate row for each polling category, these items will automatically be polled when communication is started with a control.

If *Startup Poll* is selected, these items will automatically be polled when the appropriate dialog box is opened.

Installation Directories

The following directories can be found on the installation CD.

- CPS
- CCI
- Microsoft® Upgrades

Chapter 6: Troubleshooting and Operating Tips

Cannot Communicate with a Control

If unable to receive readings or settings from a control, the problem most likely will be with the cable or the setup.

First check to be sure that the cable used is correct and that it is securely plugged into the control and into the correct port on the PC.

If the cable is secure, verify that the setup is correct. Verify that the correct control type is specified and that the communications parameters are correct.

Reports Won't Print

Reports do not print from within the CCI software. Identify the file format of the report to print. Open the appropriate software application and print from within that program.

Glossary

Baud Rate

The speed in bits per second for the serial data transfer between the computer and the control. See *Service Information S225-11-1* and *Service Information S225-10-10* for information about the baud rates the control supports.

Communications Port

The Communications Port is for use as a permanent real-time digital communications link from a control to other devices. It is not the port on the front panel of the control. See also **Data Port**.

Communications Protocol

The "language" used by the control and a PC when they communicate. When configuring a control, specify which protocol it uses. See *Service Information S225-11-1* and *Service Information S225-10-10* for information about the protocols that the control supports.

Note: The 2179 and DNP3 protocols are supported by this program. This program does not support the 2200 or 2175 protocols. The 2200 protocol was used by some versions of the CL-4C and is no longer supported. The 2175 protocol was used by the data port on CL-4 and CL-5 series controls and is no longer supported.

Control ID

The number programmed into a control to uniquely identify it. The control ID is used to find the correct configured control when communicating with a control, after clicking the Data Port button.

Control Type

Identifies the type of a control: CL-4C, CL-5A, CL-5C, CL-5D, CL-5E, or CL-6A.

Data Port

The front panel 9-pin RS-232 port on the control where a straight-through cable is attached to a computer for a temporary connection. See also **Communications Port**.

Note: The PC-to-Data Port cable used on previous CL-series controls are not used with the CL-6 control.

Demand Metering Date/Time Stamp

The demand metering values are date and time stamped for the CL-5A and later versions of controls. Date and time stamps are not available for the CL-4C control.

Reading

A reading is settings plus the output of metering, load profile, and event/profile recorders in the control. The metering, load profile, and event/profile recorder data tell you how the system and device that the control operates with is performing. The Cooper Control Interface supports receiving the readings from a control for analysis. View them on the screen and print reports. A readings file can be sent to another computer for review.

Settings

Settings are the control programming parameters that set up how the control operates. The Cooper Control Interface supports receiving the settings from a control to review them, change them, or save them for later use. Settings that were changed but not saved are displayed in blue. The program also supports creating new settings and uploading them to a control. A settings file on a computer can be transferred to another computer for review and modification, and for upload to a control attached to the PC.





© 2004 Cooper Power Systems or its affiliates.
CCI™, Cooper™ Control Interface, PMT™, SOFT-ADD-AMP™, and TIME-ON-TAP™ are trademarks of Cooper Power Systems or its affiliates.
Intel® and Pentium® are registered trademarks of the Intel Corporation in the US, and other countries.
Microsoft® Windows®, Windows NT® and Windows® XP either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
VTS™ is a trademark of Trihedral Engineering Limited.

**COOPER** Power Systems

1045 Hickory Street
Pewaukee, WI 53072
www.cooperpower.com