

200 A, 15 and 25 kV class loadbreak bushing insert installation instructions



DISCLAIMER OF WARRANTIES AND LIMITATION OF LIABILITY

The information, recommendations, descriptions and safety notations in this document are based on Eaton Corporation's ("Eaton") experience and judgment and may not cover all contingencies. If further information is required, an Eaton sales office should be consulted. Sale of the product shown in this literature is subject to the terms and conditions outlined in appropriate Eaton selling policies or other contractual agreement between Eaton and the purchaser.

THERE ARE NO UNDERSTANDINGS, AGREEMENTS, WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, OTHER THAN THOSE SPECIFICALLY SET OUT IN ANY EXISTING CONTRACT BETWEEN THE PARTIES. ANY SUCH CONTRACT STATES THE ENTIRE OBLIGATION OF EATON. THE CONTENTS OF THIS DOCUMENT SHALL NOT BECOME PART OF OR MODIFY ANY CONTRACT BETWEEN THE PARTIES.

In no event will Eaton be responsible to the purchaser or user in contract, in tort (including negligence), strict liability or otherwise for any special, indirect, incidental or consequential damage or loss whatsoever, including but not limited to damage or loss of use of equipment, plant or power system, cost of capital, loss of power, additional expenses in the use of existing power facilities, or claims against the purchaser or user by its customers resulting from the use of the information, recommendations and descriptions contained herein. The information contained in this manual is subject to change without notice.

Contents

SAFETY INFORMATION

Safety information	iv
--------------------------	----

PRODUCT INFORMATION

Introduction	1
Acceptance and initial inspection	1
Handling and storage	1
Quality standards	1

INSTALLATION INSTRUCTIONS

Installation instructions	2
---------------------------------	---

REMOVAL INSTRUCTIONS

Fault close	3
Loadbreak operation	3

OPERATING INSTRUCTIONS

Loadmake operation	4
--------------------------	---



Safety for life



Eaton meets or exceeds all applicable industry standards relating to product safety in its Cooper Power™ series products. We actively promote safe practices in the use and maintenance of our products through our service literature, instructional training programs, and the continuous efforts of all Eaton employees involved in product design, manufacture, marketing, and service.

We strongly urge that you always follow all locally approved safety procedures and safety instructions when working around high voltage lines and equipment, and support our “Safety For Life” mission.

Safety information

The instructions in this manual are not intended as a substitute for proper training or adequate experience in the safe operation of the equipment described. Only competent technicians who are familiar with this equipment should install, operate, and service it.

A competent technician has these qualifications:

- Is thoroughly familiar with these instructions.
- Is trained in industry-accepted high and low-voltage safe operating practices and procedures.
- Is trained and authorized to energize, de-energize, clear, and ground power distribution equipment.
- Is trained in the care and use of protective equipment such as arc flash clothing, safety glasses, face shield, hard hat, rubber gloves, clampstick, hotstick, etc.

Following is important safety information. For safe installation and operation of this equipment, be sure to read and understand all cautions and warnings.

Hazard Statement Definitions

This manual may contain four types of hazard statements:

DANGER

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in equipment damage only.

Safety instructions

Following are general caution and warning statements that apply to this equipment. Additional statements, related to specific tasks and procedures, are located throughout the manual.

DANGER

Hazardous voltage. Contact with hazardous voltage will cause death or severe personal injury. Follow all locally approved safety procedures when working around high- and low-voltage lines and equipment.

G103.3

WARNING

Before installing, operating, maintaining, or testing this equipment, carefully read and understand the contents of this manual. Improper operation, handling or maintenance can result in death, severe personal injury, and equipment damage.

G101.0

WARNING

This equipment is not intended to protect human life. Follow all locally approved procedures and safety practices when installing or operating this equipment. Failure to comply can result in death, severe personal injury and equipment damage.

G102.1

WARNING

Power distribution and transmission equipment must be properly selected for the intended application. It must be installed and serviced by competent personnel who have been trained and understand proper safety procedures. These instructions are written for such personnel and are not a substitute for adequate training and experience in safety procedures. Failure to properly select, install or maintain power distribution and transmission equipment can result in death, severe personal injury, and equipment damage.

G122.2

Product information

Introduction

Eaton's Cooper Power™ series loadbreak bushing insert threads into a universal bushing well to provide the same function as an integral loadbreak bushing. Using bushing inserts makes field installation and replacement possible and efficient. Bushing inserts and elbow connectors comprise the essential components of all loadbreak connections.

The bushing insert meets all the requirements of IEEE Std 386™-2006 standard and is completely interchangeable with mating products that also meet IEEE Std 386™-2006 standard. When mated with a comparably rated component, the bushing insert provides a fully shielded and submersible connection for loadbreak operation.

WARNING

All associated apparatus must be de-energized during any hands-on installation or maintenance. Failure to comply may result in death, severe personal injury, and equipment damage.

CAUTION

The 200 A loadbreak bushing insert is designed to be operated in accordance with normal safe operating procedures. These instructions are not intended to supersede or replace existing safety and operating procedures. The elbow connector should be installed and serviced only by personnel familiar with good safety practices and the handling of high-voltage electrical equipment.

Read this manual first

Read and understand the contents of this manual and follow all locally approved procedures and safety practices before installing or operating this equipment.

Additional information

These instructions cannot cover all details or variations in the equipment, procedures, or process described nor provide directions for meeting every possible contingency during installation, operation, or maintenance. For additional information, contact your Eaton representative.

Acceptance and initial inspection

Each loadbreak bushing insert is in good condition when accepted by the carrier for shipment. Upon receipt, inspect the shipping container for signs of damage. Unpack the loadbreak bushing insert and inspect it thoroughly for damage incurred during shipment. If damage is discovered, file a claim with the carrier immediately.

Handling and storage

Be careful during handling and storage of the loadbreak bushing insert to minimize the possibility of damage. If the loadbreak bushing insert is to be stored for any length of time prior to installation, provide a clean, dry storage area.

Standards

ISO 9001 Certified Quality Management System

Installation instructions

Step 1.

Clean and lubricate

- Remove red shipping cap. Do not energize bushing with shipping cap installed.
- Clean bushing well and apply a thin uniform coating of silicone lubricant. (See Figure 1.)
- Clean mating interface of bushing insert and apply a thin, uniform coating of silicone lubricant. (See Figure 2.)




Figure 1. Clean and lubricate interfaces of bushing well.




Figure 2. Clean and lubricate interface of bushing insert (15 kV version shown).

Step 2A.

Install using installation torque tool (LBITOOL)

- Insert torque tool (LBITOOL) into bushing insert, turning tool slightly to engage hex-broach.
- Place threaded end of bushing insert into bushing well.
- Turn clockwise until torque tool makes an audible “click.” The torque tool tightens the bushing insert to approximately 15 ft-lbs. (See Figure 3.)




Figure 3. Insert torque tool and tighten to bushing well (15 kV version shown).

Step 2B.

Install without using installation torque tool (LBITOOL)

- Place threaded end of bushing insert into bushing well.
- If installing using a torque tool other than the LBITOOL, the torque setting should be set for 15 ft-lbs.
- If installing without a torque tool, turn the insert clockwise until it bottoms on the bushing well stand (approximately 7 to 7-1/2 turns).

Step 3.

Ground

- Attach one end of a #14 AWG copper wire to one of the ground tabs of the bushing insert.
- Attach other end of wire to ground. (See Figure 4.)



Figure 4. Attach ground lead (15 kV version shown).

Step 4.

Cover interface

- Do not leave bushing interface exposed.
- Cover with an appropriate mating product using the instructions supplied. **DO NOT USE SHIPPING CAP.**

ATTENTION: This bushing is equipped with Eaton's exclusive latch indicator ring, that serves as a visual indicator to verify that the mating component is properly seated on the bushing insert.

Once the mating component has been properly installed on the bushing, the yellow ring should be completely covered.

If any yellow is visible, the elbow or protective cap must be completely installed or "latched" before energizing to assure a quality connection.

Removal instructions

- De-energize apparatus and verify apparatus is de-energized.
- Remove mating products and place in stand-off device or in a clean, dry location.
- Remove ground wire.
- Use either a 5/16" hex drive tool, torque tool or a strap wrench to remove.
 - If a hex-drive tool is used, insert drive into insert, turning tool slightly to engage hex-broach. Turn counter-clockwise to remove.
 - If a strap wrench is used, wrap around the collar of the bushing insert. Turn counter-clockwise to remove. Take care not to damage bushing interface during this procedure.

Fault close

1. It is not recommended that operations be made on known faults.
2. If a fault is experienced, both the elbow connector and the bushing must be replaced.

Loadbreak operation

1. Securely fasten a clampstick to the pulling eye of the mating loadbreak elbow.
2. Without exerting any pulling force, slightly rotate the elbow clockwise to break surface friction between the elbow and bushing.
3. Withdraw the elbow from the bushing with a fast, firm, straight motion, being careful not to place the connector near a ground plane.
4. Place the elbow on an appropriate accessory device, following the operating instructions for that accessory.
5. Place an insulated protective cap with drain wire attached to system ground on any exposed energized bushing using a clampstick.

 **WARNING**

The operator should always use personal protective equipment (insulated gloves, clampstick and eye protection) whenever operating the elbow. The operator should always be in the best possible operating position, providing firm footing and enabling a secure grasp of the clampstick, while maintaining positive control of the elbow before, during and immediately after operation. If there is any question regarding the operator's operating position, de-energize the elbow before operation. The operator should not be looking directly at the connector during the moment of circuit interruption or connection. Failure to comply may result in death, personal injury and equipment damage.

Operating instructions

Do not connect two different phases of a multiple-phase system. Before closing a single-phase loop, make certain both ends of the loop are the same phase.

Loadmake operation

1. Area must be clear of obstructions or contaminants that would interfere with the operation of the loadbreak elbow.
2. Securely fasten a clampstick to the pulling eye.
3. Place the loadbreak elbow over the bushing, inserting the white arc follower of the probe into the bushing approximately 2-1/2" until a slight resistance is felt.
4. Immediately thrust the elbow onto the bushing with a fast, firm, straight motion, with sufficient force to latch the elbow to the bushing.
5. Push again on the elbow with the clampstick, and then pull gently to make sure that it is secure.



Eaton
1000 Eaton Boulevard
Cleveland, OH 44122
United States
Eaton.com

**Eaton's Cooper Power Systems
Division**
2300 Badger Drive
Waukesha, WI 53188
United States
Eaton.com/cooperpowerseries

EATON
Powering Business Worldwide

© 2015 Eaton
All Rights Reserved
Printed in USA
Publication No. MN650013EN Rev 0
(Supersedes S500121 Rev 2)

Eaton is a registered trademark.

All other trademarks are property
of their respective owners.

For Eaton's Cooper Power series product
information call 1-877-277-4636 or visit:
www.eaton.com/cooperpowerseries.