


Form 6 Control Reference



Read equipment manufacturer's manual and this material before using this product. Failure to do so can result in death, severe personal injury, and equipment damage. G164.0



Note: This reference card only applies to the standard, factory-default control.

Control / Recloser Status

Status of the recloser and control are easily viewed via the operator panel. Press any key to wake the operator panel.

- **CONTROL OK:** Normally on. The CONTROL OK LED will extinguish if certain battery, RAM, ROM, AC, Power Supply, and/or RIF alarms are active.
- **CONTROL POWER:** An illuminated CONTROL POWER LED indicates there is adequate VTC voltage to successfully trip (or close) the mechanism. It does NOT indicate the presence of AC or battery power.
- **CONTROL LOCKOUT:** On only when the control is in a Locked-Out state. It does NOT indicate the recloser is open.
- **RECLOSER OPEN:** On only when the Recloser is Open.
- **RECLOSER CLOSED:** On only when the Recloser is Closed.

Hot Keys

A **LAMP TEST** key, **CHANGE** key and six (6) HOT keys provide instant, direct-access, to the following menu items:

- **METERING:** Press to view instantaneous current and voltage metering values.
- **RESET TARGETS:** Press to immediately reset FAULT TARGET indicators on the operator panel.
- **EVENTS:** Press EVENTS and ENTER to view the 25 most recent events. Navigate through the Sequence of Events (SOE) using the UP and DOWN arrows.

- **SETTINGS:** Press to gain instant access for viewing or modifying recloser settings on the LCD display.
- **OPERATIONS COUNTER:** Press for instant access to view the Trip Counter and Target Counters for each Phase, Ground, and SEF. Two reset functions are also available: RESET TARGET COUNTERS and RESET TRIP COUNTER.
- **ALARMS:** Press to view alarm status. Active alarms are indicated by a "1", inactive alarms are indicated by a "0".

Navigating the LCD Display

Note: The LCD display panel contrast is field-adjustable to allow for various mounting heights and applications. Press the MENU key and then press the (+) or (-) key to increase or decrease the contrast.

- **LCD FUNCTION KEYS (F1, F2, F3, F4):** The four LCD menu function keys activate specific menu commands. When a command appears in the LCD display directly above one of the four LCD menu function keys, press the key to accept/select the command.

Note: Function keys are not active in all menus.

- **MENU:** The MENU key displays the root menu. It also returns the display to the previous menu each time it is pressed.
- **ENTER:** The ENTER key is used for the following:
 - Confirm a settings modification.
 - Confirm a selection from within a MENU.
- **(+ and -) Keys:** are used to step through values when in the MODIFY / SETTINGS mode.
- **ARROW Keys:** Navigate vertically through the displayed MENU using the UP and DOWN arrow keys; arrow keys are located just below the display. In some menus, the cursor position can be moved horizontally using the LEFT and RIGHT arrow keys.
- **RESET ALARMS:** Press the ALARMS hotkey, move the cursor (>) to the left of the RESET ALARMS menu item, press the ENTER key, then the F4 function key.

Basic Control Operations


- **CHANGE:** The CHANGE key must be pressed prior to actuating any of the nine (9) Function Key Buttons.

Note: The CHANGE key remains active for 10 seconds after which time the LCD display returns to the basic menu.

- **LAMP TEST:** When the LAMP TEST feature is actuated, all front panel LEDs will illuminate for approximately five seconds.
- **TRIP:** Pressing the TRIP pushbutton trips the recloser to the "RECLOSER OPEN" position and places the control in "CONTROL LOCKOUT" mode (automatic reclosing is inhibited).
- **CLOSE:** Pressing the CLOSE pushbutton closes the recloser. The control is now ready to follow OCP programming.



Powering Business Worldwide



Hot Line Tag

Provided for live-line work applications.

- Does not cause the recloser to trip open. It only prevents the recloser from closing.
- Prevents all closing attempts from the control and shifts protection to one trip-to-lockout on the composite curve of the Hot Line Tag definite time and the TCC1 curve (whichever is faster). Takes precedence over Cold Load Pickup, Non-Reclosing, and Fast Trips Disabled.
- Activated from either the operator front panel toggle switch, local or remote communications, or configurable logic.
- Can only be reset by the source which initiates it.

Default Function Key Buttons

Also, refer to the "CHANGE" key description.

- **GND TRIP BLOCKED:** Blocks all ground sensing in the control for the active profile.
- **NON-RECLOSING:** Places the control in 1-Shot-to-Lockout mode. When activated, the control will follow the next programmed TCC and a "Control Lockout" will follow the OCP trip event.
- **SUPERVISORY OFF:** When activated, supervisory commands via Contact I/O or any of the communications accessories are ignored.
- **ALTERNATE PROFILE BUTTONS:** There are four separate protection profiles: Normal and Alternate Profiles 1, 2, and 3. Each profile changes all protection parameters. When pressed, the respective profile becomes the active profile. If the LED is illuminated and the button is pressed again, the NORMAL profile will become the active profile.

Important: Check minimum trip values prior to changing an alternate profile to avoid misoperation of the control under load conditions.

- **OPTION BUTTONS:** Three (3) OPTION buttons are unassigned by default.

Note: All nine (9) function key buttons can be customized via the Idea Workbench™.

Note: Loop Scheme (LS) and Triple-Single (TS) controls incorporate different Function Key default function configurations.

View / Change Settings


Step 1. Press the SETTINGS hotkey, the LCD will display: "Mod/View Settings."

Step 2. Press the ENTER key, the LCD will display « Enter Password ». The default password is «0» - therefore, if a password has not been assigned just press the ENTER key again, otherwise, enter your password and then press ENTER.

Hint: Use the + and – keys to enter a password. Press-and-hold the key to skip through the values faster.

Accept / Cancel Settings Change

Following a settings change press the ENTER key and then the MENU key – the screen shot shown below will be displayed.



If you made a change to one or more settings either:

- Accept and USE a changed setting – press the F1 function key.
- REVERT to the previously saved setting – press the F2 function key.
- Step BACK to the previous dialog – press the F4 function key.

Refer to the Form 6 Control Installation Instructions included with this control for additional information. **Contact the Switchgear Support Group 1-800-497-5953 for assistance, 24/7 emergency support also available.**



Eaton
1000 Eaton Boulevard
Cleveland, OH 44122
United States
Eaton.com

Eaton's Power Systems Division
2300 Badger Drive
Waukesha, WI 53188
United States
Eaton.com/cooperpowerseries

© 2018 Eaton
All Rights Reserved
Printed in USA
Publication No. MZ280006EN / CSSC-1809-6025
KA2048-0719 REV 02
November 2018
Supersedes 4/2015 (B280-12010)

Eaton is a registered trademark.

All other trademarks are property of their respective owners.

Follow us on social media to get the latest product and support information.

