


ULCTPR3000 Analogue Touchscreen Repeater Panel

Installation and Operation Manual

SIGNALING



LISTED
FIRE ALARM
EQUIPMENT
4AC5



EATON

Powering Business Worldwide

Contents

- SYSTEM INSTALLATION AND DESIGN7**
 - Introduction7
 - Installation Precautions9
 - Panel Controls & Indicators11
 - Technical Specification12
 - Installation13
 - Fixing details13
 - External Connections14
 - Networking16
 - Cable Wiring16

- COMMISSIONING THE PANEL19**
 - Commissioning19

- PANEL CONTROLS AND INDICATORS20**
 - Touch Screen Display20
 - Panel Operation21
 - Public Access Level 122
 - Evacuate (Access Level 2)23
 - Silence Alarms24
 - Mute Buzzer25
 - Reset25
 - Pre-Alarms26
 - Disabled Devices26
 - Faults27
 - Enable/Disable (others Menu)27
 - Enable/Disable28
 - Print (function not available)29
 - Lamp Test30
 - Viewing Events31
 - Send Log to PC32
 - Erase Log33
 - System Details34
 - Load Logo from PC35

Repeater Mode	36
Printer Settings	37
Change Panel Number	38
Number of Panels in Network	39
Change Date/Time.	40
Change Panel Text	41
Change Passcode	42
Relay Control	43
Programmable Input	44
Network.	45
Language.	46
Network Protocol.	47
Power Supply.	48
Password Protection	49

DOCUMENT UPDATE NOTES

S.No.	Release / Change Notes	Date
A	Eaton Update	January 2019

PROPRIETARY NOTICE

All data and information contained within this manual is of a proprietary nature. Do not reproduce, transcribe, store in a retrieval system or translate into any language, any part of this manual without the prior permission of 'EATON'. EATON reserves the right to make changes to product specification without notice or liability. Every care has been taken to ensure the accuracy of the information contained in this manual, but no liability can be accepted for any errors or omission.

DISCLAIMER OF WARRANTIES AND LIMITATION OF LIABILITY

The information, recommendations, descriptions and safety notations in this document are based on Eaton Corporation's ("Eaton") experience and judgment and may not cover all contingencies. If further information is required, an Eaton sales office should be consulted. Sale of the product shown in this literature is subject to the terms and conditions outlined in appropriate Eaton selling policies or other contractual agreement between Eaton and the purchaser.

THERE ARE NO UNDERSTANDINGS, AGREEMENTS, WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, OTHER THAN THOSE SPECIFICALLY SET OUT IN ANY EXISTING CONTRACT BETWEEN THE PARTIES. ANY SUCH CONTRACT STATES THE ENTIRE OBLIGATION OF EATON. THE CONTENTS OF THIS DOCUMENT SHALL NOT BECOME PART OF OR MODIFY ANY CONTRACT BETWEEN THE PARTIES.

In no event will Eaton be responsible to the purchaser or user in contract, in tort (including negligence), strict liability or other-wise for any special, indirect, incidental or consequential damage or loss whatsoever, including but not limited to damage or loss of use of equipment, plant or power system, cost of capital, loss of power, additional expenses in the use of existing power facilities, or claims against the purchaser or user by its customers resulting from the use of the information, recommendations and descriptions contained herein. The information contained in this manual is subject to change without notice.

SUPPORT SERVICES

The goal of Eaton is to ensure your greatest possible satisfaction with the operation of our products. We are dedicated to providing fast, friendly, and accurate assistance. That is why we offer you so many ways to get the support you need. Whether it is by phone, fax, or email, you can access Eaton's support information 24 hours a day, seven days a week. Our wide range of services is listed below. You should contact your local distributor for product pricing, availability, ordering, expediting and repairs.

Website

Use the Eaton website to find product information. You can also find information on local distributors or Eaton's sales offices.

www.eaton.com

EatonCare Customer Support Center

Call the EatonCare Support Center if you need assistance with placing an order, stock availability or proof of shipment, expediting an existing order, emergency shipments, product price information, returns other than warranty returns, and information on local distributors or sales offices.

Voice: 877-ETN-CARE (386-2273) (8:00 a.m. to 6:00 p.m. EST)

After-Hours Emergency: 800-543-7038 (6:00 p.m. to 8:00 a.m. EST)

Important Safety Information

Personnel who install, maintain or repair this equipment must read the safety information below before starting work.

WARNING

Indicates a potentially hazardous situation which, if not avoided, can result in serious injury or death.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, can result in minor to moderate injury, or serious damage to the product.

General Safety Precautions

NOTICE

The operating system of the control panel may be revised as a result of enhancements to the system software or hardware. Revisions to this manual will be issued and supplied on request and should be logged in the table supplied on page 4.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE

This product must only be disposed of in accordance with the WEEE directive.



System Installation and Design

Introduction

This manual provides information on the installation and operation of the Eaton Fire Systems ULCTPR3000 repeater panel.

Notice. This passive repeater is used for supplementary information only. The operating system of the ULCTPR3000 may be revised as a result of enhancements to the system software or hardware.

THIS PRODUCT INCORPORATES FIELD-PROGRAMMABLE SOFTWARE. IN ORDER FOR THE PRODUCT TO COMPLY WITH THE REQUIREMENTS IN THE STANDARD FOR CONTROL UNITS AND ACCESSORIES FOR FIRE ALARM SYSTEMS, UL 864, CERTAIN PROGRAMMING FEATURES OR OPTIONS MUST BE LIMITED TO SPECIFIC VALUES OR NOT USED AT ALL AS INDICATED BELOW

PROGRAM FEATURE OR OPTION	PERMITTED IN UL 864	POSSIBLE SETTINGS	SETTINGS PERMITTED IN UL 864
ACTIVE	NO	ACTIVE/PASSIVE	PASSIVE
PROGRAMMABLE INPUT	NO	RESET, FIRE, EVACUATE, PRE-ALARM, SILENCE, FAULT	NOT USED

For maintenance recommendations refer to the NFPA 72 National Fire Alarm Code, 2007.

Software release: DFCF V03-03-50-xx

Fire Alarm System Limitations

An automatic fire alarm system – in general is made up of smoke detectors, heat detectors, manual pull stations, Call points, audible warning devices, and fire alarm control panels with remote notification capability, which can supply early warning of a developing fire. Such a system, on the other hand, is unable to assure protection against property damage or loss of life resulting from a fire. The Manufacturer recommends that smoke and /or heat detectors must be positioned throughout a protected premise following the recommendations of the current edition of the National Fire Protection Association Standard 72 (NFPA72), manufacturer’s recommendations, State and local codes, and the recommendations contained in the Guide for Proper Use of System Smoke Detectors, which is made available at no charge to all installing dealers. A study by the Federal Emergency Management Agency (an agency of the United States government) indicated that smoke detectors may not go off in as many as 35% of all fires. While fire alarm systems are intended to provide early warning against fire, they cannot promise warning or protection against fire. A fire alarm system may not provide timely or sufficient notice, or might not function, for a diversity of reasons.

System Installation and Design

Smoke detectors may not sense fire where smoke cannot reach the detectors such as in chimneys, in or behind walls, on roofs, or on the other side of closed doors. Smoke detectors also may not sense a fire on another level or floor of a building. A second-floor detector, for example, may not sense a first-floor or basement fire. Particles of combustion or “smoke” from a developing fire may not reach the sensing chambers of smoke detectors because:-

- Barriers such as closed or partially closed doors, walls, or chimneys may inhibit particle or smoke flow.
- Smoke particles may become “cold,” stratify, and not reach the ceiling or upper walls where detectors are located.
- Smoke particles may be blown away from detectors by air outlets.
- Smoke particles may be drawn into air returns before reaching the detector.

The amount of “smoke” present may be insufficient to alarm the smoke detectors. Smoke detectors are designed to alarm at various levels of smoke density. If such density levels are not created by a developing fire at the location of detectors, the detectors will not go into alarm. Smoke detectors, even when working properly, have sensing limitations. Detectors that have photo electronic sensing chambers tend to detect smoldering fires better than flaming fires, which have little visible smoke. Detectors that have ionizing-type sensing chambers tend to detect fast –flaming fires better than smoldering fires. Because fires develop in different ways and are often unpredictable in their growth, both type of detector is necessarily best and a given type of detector may not provide adequate warning of a fire. Smoke detectors cannot be expected to provide adequate warning of fires caused by arson, children playing with matches (especially in bedrooms), smoking in bed, and violent explosions (caused by escaping gas, improper storage of flammable materials, etc.).

Heat detectors do not sense particles of combustion and alarm only when heat on their sensors increases at a preset rate or reaches a predetermined level. Rate-of-rise heat detectors may be subject to reduced sensitivity overtime. For this reason, the rate-of-rise feature of each detector should be tested at least once per year by a qualified fire protection expert. Heat detectors are designed to protect property, not life.

IMPORTANT! Smoke detectors must be installed in the same room as the control panel and in rooms used by the system for the connection of alarm transmission wiring, communications, signaling, and/or power. If detectors are not located, a developing fire may damage the alarm system, crippling its ability to report a fire.

Audible warning devices such as bells may not alert people if these devices are located on the other side of closed or partly open doors or are located on another floor of a building. Any warning device may fail to alert people with a disability or those who have recently consumed drugs, alcohol or medication.

Please note that:

Strobes can, under certain circumstances, cause seizures in people with conditions such as epilepsy. Studies have shown that certain people, even when they hear a fire alarm signal, do not respond or comprehend the meaning of the signal. It is the property owner's responsibility to conduct fire drills and other training exercise to make people aware of fire alarm signals and instruct them on the proper reaction to alarm signals.

In rare instances, the sounding of a warning device can cause temporary or permanent hearing loss.

A fire alarm system will not operate without any electrical power. If AC power fails, the system will operate from standby batteries only for a specified time and only if the batteries have been properly maintained and replaced regularly. Equipment used in the system may not be technically compatible with the control. It is essential to use only equipment listed for service with your control panel. Telephone lines needed to transmit alarm signals from a premise to a central monitoring station may be out of service or temporarily Supervisory. For added protection against telephone line failure, backup radio transmission systems are recommended.

The most common cause of fire alarm malfunction is insufficient maintenance. To keep the entire fire alarm system in excellent working order, ongoing maintenance is required as the manufacturer's recommendations, and UL and NFPA standards. At a minimum, the requirements of NFPA 70, 72 shall be followed. Environments with large amounts of dust, dirt or high air velocity require more frequent maintenance. A maintenance agreement should be arranged through the local manufacturer's representative. Maintenance should be scheduled monthly or as required by National and /or local fire codes and should be performed by authorized professional fire alarm installers only. Adequate written records of all inspections should be kept.

Installation Precautions

WARNING

Several different sources of power can be connected to the fire alarm control panel. Disconnect all sources of power before servicing the Control unit and associated equipment may be damaged by removing and/or inserting cards, modules or interconnecting cables while the unit is energized. Do not attempt to install, service, or operate this unit until this manual is read and understood fully.

CAUTION

System Reacceptance Test after Software Changes. To ensure proper system operation, this product must be tested in accordance with NFPA 70, 72 after any programming operation or change in site -specific software. Reacceptance testing is required after any change, addition or deletion of system

System Installation and Design


The ULCTPR3000 fire detection repeater panel provides sophisticated 'touch screen' functionality yet achieves a simple end-user interface operation within a compact panel design. The ULCTPR3000 is designed to work with Eaton Analogue Addressable Fire alarm Control Panels as a network repeater. It is fully compliant with the statutory requirement of UL854 9th Edition and includes an integral monitor PSU compliant with the latest requirements of EN54 pt4 together with a wide range of user controllable functions; make the panel suitable for a wide range of projects.

The Eaton repeater panel is easy to install and commission all text is transmitted via the network and is automatically updated and as the following features:

- Plug and play. All information is downloading through the network
- Touch Screen Display
- Integrated Network capability allows networking with Eaton latest range of analogue addressable Fire Alarm Control Panels
- Multi language capability
- 2 Form C programmable Auxiliary relays
- Programmable input is available
- Up to 1000 event log
- PSU approved to UL 864 9th Edition & EN54 Pt4
- Utilises 2 core cables and up to 126 repeaters can be connected to the network

Panel Controls & Indicators

1. System LED's
2. Zonal LED's
3. Touch Screen Display



LED	Name	Function	Action
1	Power On	Shows Panel is On	Check Indicator is Illuminated
2	Fire	Indicators Panel has Detected a Fire	Implement Fire Action Procedure
3	General Fault	Monitors Devices for Faults e.g. Smoke detectors/Sounders	Report to System Supervisor
4	General Disable	Monitors Fire Panel for Faults	Report Fault to Service Dept
5	Power Fault	Monitor Internal Battery Charger	Report Fault to Service Dept
6	System Fault	Monitors Fire Panel for Faults	Report Fault to Service Dept
7	Test	Supervisor/Engineer is Testing the Systems	Report to System Supervisor
8	Sounder	Indicates the Sounder Status	Check with System Supervisor

System Installation and Design

Technical Specification

Compatibility	With UL Addressable Panels
Standards	UL864 9th Edition NFPA 70-72
Display	Touch Screen
System Indicators	Power on, Alarm, General Trouble, General Supervisory, Power Trouble, System Trouble, Test, NAC Trouble.
Colour	Graphite
Network SLC	5V DC, 11 mA max Maximum Line impedance 50Ω Power Limited
Mains Input, Supervised	Voltage 120/240 AC 60Hz Current 100mA
Batteries	2x12V DC, 7Ah, 0.1 derating
Battery Charge Current	1.0 Amp
Standby period	24 hours + 30min. alarm
Programable Relay (Fire)	30V, 1 Amp, Resistive
Humidity (Non Condensing)	0 - 93 %RH
Operating Temp	0 to 49 degree C
Mechanical	PC/ABS, UL94 5VA rating
Weight	9Kg (with batteries) 4Kg (without batteries)
Dimensions	395(h)x332(w)x115(d)mm
IP Rating	IP40 - for indoor applications
Cable Entry	11x20mm knockouts top of backbox
Download Comms	RS232 port

Installation

Fixing details


Read all the installation instructions before commencing with the installation. The installation of this panel must be carried out by a suitably qualified /trained person.

The electronic components within the fire panel are Static Sensitive. Do not touch the electronics directly.

General

As with all electrical equipment the ULCTPR3000 panels should be installed in a clean, dry, well ventilated area, away from direct sunlight. The unit is designed to operate in temperatures between 0° and 49°C, temperatures outside these parameters should be avoided. The panel should be located away from any potential hazard, in a position where it is readily accessible to both the fire services and authorised users, ideally on the perimeter of the building near a designated entrance point.

Mounting the Backbox



System Installation and Design

External Connections

Installing Cabling

Once the backbox is mounted the next stage is to install the power and loop cables and fit the glands.

Connecting the AC Power and earth connection



To reduce the risk of electrical shock, make sure that all power has been turned off or disconnected prior to attempting to connect power to the Power Supply.

Note: Make sure that AC main circuit breaker is off before wiring any connection between mains and control panel


The primary power needed for the Addressable Repeater Panel is 120VAC 60hz or 240VAC 60Hz.

1. Enter Power Cable into Cabinet knock out hole.
2. Attach the brown (live) wire from the source to terminal "Line" (USA use color black wire).
3. Attach the blue (neutral) wire from the source to the "Neutral" terminal (USA use color white wire).
4. Attach the ground wire from the source to the "GD" terminal block (USA use color green wire).

Cable Anchorage

The mains cable must be fixed securely with a 20mm cable gland. Remove a suitably located knockout feed the cable through the gland and bolt the gland to the Backbox as shown. Secure the cable to the side of the box using the cable clip provided.

Connect wiring from AC mains to TB100 on the PCBA2209 being careful to observe proper connections in the figure below.




Note: Apply the AC Power BEFORE connecting the batteries to the Panel!

Note: Apply AC power to panel after the system is completely installed and visually checked.

Battery Installation

The battery is placed at the bottom of the enclosure. The ULCTPR3000 is fully protected if the batteries are connected in the opposite direction the battery fault yellow led will show steady in such a condition.



System Installation and Design

Networking

Up to One Hundred & Twenty Six Panels or repeaters can be networked together to operate as a single networked system. To achieve this each panel must be fitted with a network card (Optional Extra) When operating as a networked system all fire and fault event information is displayed at every panel, silencing and resetting of alarms can also be carried out from any panel on a networked system if panels are suitably configured.

Networked panels are connected using a loop topology as illustrated.

Networked panels can be used as active repeaters, alternatively a low cost passive repeater is available. This can either be connected a loop of an individual panel or it can be connected to the network.

The recommended network cable for the network connection between panels is an enhanced Firetuf cable Manufactured by Draka cables (part number 910234.) Screen continuity must be maintained throughout the entire network circuit including at each junction point. The screen should only be earthed at the connection point provided at the first panel and not at any other point. The screen or drain wire of the network cable should not be considered as a safety earth and therefore should not be connected to terminals marked with the earth symbol, except at the panel, and should not be insulated with green and yellow sleeving. Where the network cable passes between buildings, screen continuity should not be maintained from building to building. A booster device must however be used irrespective of cable length and should be fitted at a suitable point in the link between buildings. The cable screen should be connected to the earth of one panel in each building. 102 S terminator should be fitted at the beginning and the end of the network. If the distance in the network exceeds 1KM the booster should be used. The booster requires 24V local supply, which can be connected to nearest Addressable Panel.

Cable Wiring

Only the cable types listed below are allowable for loop connections.
DRAKA Cables (Part Number 910234)

Technical Specification



Cabling Application	Applicable Standards
Circuit integrity Structured Wiring	ISO/IEC 11801:95
Alarm/Lighting Cable Part Number 910234	EN 50173:95
Patent Protected Design	Fire Propagation Test : UL 1581 VW1; IEC60332.3; Cct Integrity tests: IEC 60331; BS5839: 2002

Cable construction

Conductor	Bare Cu	Outside Diameter of Conductor	0.65 mm
Insulator Material	Wire	Outside Diameter of Insulation	1.70 mm
Number of Twisted Pairs	PE/Sil Rbr	Outside Diameter of Sheath	5.3 mm
Glass Tape	1	Weight OHLS	15.8 kg/km
Screen Material	Mica	Sheath Colour (OEM Specified)	Various
Braid	Ali/Mylar	Sheath Printing (up to 24 characters)	Batch No. & Metre marking
Sheath Material	TCWB OHLS		

Cable Properties

Electrical Characteristics @ 20 °C

Min. Installation Bend Radius	8 x Dia	Return Loss RI	>IEC dB
Min. Installed Bending Radius	4 x Dia	Characteristic impedance @	100±5Ω
Max. Installation Tension	50N	10MHz	30 Ω/100m
Max. Installed Tension	Zero	DC Conductor Loop Resistance	±2%
InstTemp. Range Installed	0 to 0°C	Max. Resistance unbalance	57%
Operating Temp. Range	-20 to 60°C	Nominal Velocity of Propagation	≈5000
		Insulation Resistance (500V)	MΩ.km
		300/500v ratedq	

Fire tests BS 5839: 2002 & IEC60331

Continued Data Operation @ 950°	>3 Hours
Smoke test	passed
Approvals	passed

When choosing your preferred cable type, you must take note of the following cable and wiring requirements:

1. The cable must be 2 core screened with an over sheath.
2. Maximum loop length with any of the above cables is 1KM
3. Multicore cable should not be used for detector wiring.
4. The screen or drain wire of the network cable should not be considered as a safety earth.
5. Screen continuity must be maintained throughout the entire network circuit including at each junction point.
6. Where the network cable passes between buildings, screen continuity should not be maintained from building to building. A booster device must however be used irrespective of cable length and should be fitted at a suitable point in the link between buildings. The cable screen should be connected to the earth of one panel in each building.

System Installation and Design

Based on the above cable, the maximum acceptable length between signal boosters is 1000 Metres. This distance can only be achieved when the above cable is used, Eaton lighting and security does not recommend the use of other network cables.


Once the maximum cable length has been reached, a booster must be fitted which then allows a further length of the same distance (1000 Metres for the recommended cable). A maximum of 5 network boosters can be used

N.B. Repeater control panels do not act as boosters, therefore the location of such panels is irrelevant when calculating cable lengths and the requirement for booster devices. For convenience when using 24V boosters (see following) it may be desirable to house the booster near to a repeater control panel to derive a convenient power supply.

Note: Eaton Network cards are fitted with loop terminators as standard please cut if not required.

Daisy Chain configuration

Redundant Network



Commissioning the Panel

Commissioning

The Eaton Repeater is a plug & play technology where downloading of text information through a PC is not required as the text information is downloaded via the network.

1. Supply the network address (page 45)
2. Select the repeater mode information (page 36)
3. Program the relays output and programable input if required (page 43 & 44)
4. Select the power supply option (page 48)

Panel Controls and Indicators

Panel Controls and Indicators

Touch Screen Display

Supervisor	Fires 0	Pre Alarms 0	Faults 0	Disabled 0
Repeater Panel System Healthy				
Tuesday dd-mm-yyyy				
16:25.25 BST On				

The Touch Screen is a multi-function display consisting 320x240 dots featuring high intensity backlighting. In normal operation, the display indicates as above with the backlighting off.

During an event on the system the display shows the FIRST EVENT and LAST EVENT plus other events as space allows.

The last 2 lines are normally used to display the total number of events, but they are also used for scrolling fire conditions, faults, pre alarms or disabled devices independently or for displaying a reduced menu when in fire condition.

When an event occurs the Touch Screen backlighting comes on unless there is a mains power supply fault.


Use the Touch Screen to scroll through all active events on the system by using the SCROLL UP and SCROLL DOWN buttons (available at access level 1). You can display the contents of the log and also view details of any fires, faults, pre-alarms, faults or disablements.. When displaying the system menu on the Touch Screen, the last 5 lines of the display are shown in reverse text.

Panel Operation

The Panel is operated via a backlit touch screen. The default fire screen is shown below. From this screen all the panels functions can be operated. The first time you touch the screen the backlight will illuminate the panel.

Supervisor	Fires 0	Pre Alarms 0	Faults 0	Disabled 0
<p>Repeater Panel System Healthy</p> <p>Tuesday dd-mm-yyyy</p> <p>16:25.25 BST On</p>				

Pressing a field will highlight it and forward to the next screen as shown below.



Panel Controls and Indicators

Public Access Level 1

Public access level does not require an access code and allows anybody to review the functions outlined below.

Public access level

Supervisor	Fires 0	Pre Alarms 0	Faults 5	Disabled / Test
Repeater Panel System Healthy				
Tuesday dd-mm-yyyy 16:25.25 BST On				

Supervisor	Fires 1	Pre Alarms 0	Faults 0	Disabled / Test
First Fire	12:26:23 Device 1, Zone 1 Lp: 1, Ad:1, Z:1, Opto/thermal, [69]			
Total Fires= 1	Print All		Help	
Tuesday dd-mm-yyyy 16:25.25 BST On				

Supervisor	Fires 0	Pre Alarms 6	Faults 0	Disabled / Test
Show Addresses	Show Zones	Show I/O	Show Test Zone	
Print All		Help		↑
001	Device 2, Zone 1 Loop 1, Zone: 1, Type : Opto/thermal			
002	Device 3, Zone 1 Loop 1, Zone: 1, Type : Opto/thermal			
003	Device 4, Zone 1 Loop 1, Zone: 1, Type : Opto/thermal			
004	Device 5, Zone 1 Loop 1, Zone: 1, Type : Opto/thermal			
				↓

Supervisor	Fires 0	Pre Alarms 6	Faults 0	Disabled / Test
Print All		Help		
001	03-Jun-03 12:51 Warning! : Device1 Lp: 1, Ad: 1, Z: 1, Opto/thermal [69]			
002	03-Jun-03 12:51 Warning! : Device2 Lp: 1, Ad: 2, Z: 1, Opto/thermal [69]			
003	03-Jun-03 12:51 Warning! : Device3 Lp: 1, Ad: 3, Z: 1, Opto/thermal [69]			
004	03-Jun-03 12:51 Warning! : Device4 Lp: 1, Ad: 4, Z: 1, Opto/thermal [69]			
005	03-Jun-03 12:51 Warning! : Device5 Lp: 1, Ad: 5, Z: 1, Opto/thermal [69]			
				↓

Supervisor	Fires 0	Pre Alarms 6	Faults 5	Disabled / Test
Print All		Help		
001	12:31:59 Fault! : Device1 Lp: 1, Ad: 1, Z: 1, Opto/thermal [0]			
002	12:32:59 Fault! : Device2 Lp: 1, Ad: 2, Z: 1, Opto/thermal [69]			
003	12:33:59 Fault! : Device3 Lp: 1, Ad: 3, Z: 1, Opto/thermal [69]			
004	12:34:59 Fault! : Device4 Lp: 1, Ad: 4, Z: 1, Opto/thermal [69]			
005	12:35:59 Fault! : Device5 Lp: 1, Ad: 4, Z: 1, Opto/thermal [69]			
				↓

Evacuate (Access Level 2)

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the passcode.

Enter the Supervisor Mode Passcode and select "Evacuate" on the menu at the top of the screen.

Supervisor	Evacuate	Silence Alarms	Mute Buzzer	Reset
View Fires AC = 0	View Pre Alarms	Disabled	Faults	Others
<p>Pre-alarm = Some smoke/heat but below fire threshold. Disabled = Detectors, alarms etc that are switched off. Faults = Short circuits, broken detectors etc. Others = Enabled/Disabled, printing log, tests etc.</p> <p>To silence all alarms, touch "Silence Alarms" To activate all alarms, touch "evacuate".</p>				

Select "Yes" to evacuate the building.

This will activate ALL sounders
and activate all panel relays
Do you wish to continue?

Panel Controls and Indicators

Silence Alarms

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the passcode.

Enter the Supervisor Mode Passcode and select "Silence Alarms" button as the top of the screen.

Supervisor	Evacuate	Silence Alarms	Mute Buzzer	Reset
View Fires AC = 0	View Pre Alarms	Disabled	Faults	Others
<p>Pre-alarm = Some smoke/heat but below fire threshold. Disabled = Detectors, alarms etc that are switched off. Faults = Short circuits, broken detectors etc. Others = Enabled/Disabled, printing log, tests etc.</p> <p>To silence all alarms, touch "Silence Alarms" To activate all alarms, touch "evacuate".</p>				

Select "yes" to silence Alarm.

This will silence ALL sounders
Do you wish to continue?

Yes

No

Mute Buzzer

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the passcode.

Enter the Supervisor Mode and Select "Mute Buzzer" from the Top Menu

Supervisor	Evacuate	Silence Alarms	Mute Buzzer	Reset
<div style="display: flex; justify-content: space-between; border-bottom: 1px solid black; padding-bottom: 5px;"> View Fires AC = 0 View Pre Alarms Disabled Faults Others </div> <p>Pre-alarm = Some smoke/heat but below fire threshold. Disabled = Detectors, alarms etc that are switched off. Faults = Short circuits, broken detectors etc. Others = Enabled/Disabled, printing log, tests etc.</p> <p>To silence all alarms, touch "Silence Alarms" To activate all alarms, touch "evacuate".</p>				

Reset

Enter the Supervisor Mode and Select "Reset" from the top Menu. Select "Yes" to reset the panel.

Supervisor	Evacuate	Silence Alarms	Mute Buzzer	Reset
<div style="display: flex; justify-content: space-between; border-bottom: 1px solid black; padding-bottom: 5px;"> View Fires AC = 0 View Pre Alarms Disabled Faults Others </div> <p>Pre-alarm = Some smoke/heat but below fire threshold. Disabled = Detectors, alarms etc that are switched off. Faults = Short circuits, broken detectors etc. Others = Enabled/Disabled, printing log, tests etc.</p> <p>To silence all alarms, touch "Silence Alarms" To activate all alarms, touch "evacuate".</p>				

➔

This will Reset the Panel
Do you want to continue?


Yes

No

Panel Controls and Indicators

Pre-Alarms


Enter the Supervisor Mode and Select “Pre-Alarms” tab.



A pre-alarm is shown when a detector appears to register heat or smoke but in a quantity that is insufficient to warrant an alarm. Pre-alarm may indicate a build up of dirt in a smoke detector which can be interpreted by the detector as smoke presence.

Disabled Devices


Enter the Supervisor mode and Select the “Disabled” tab.



The individual buttons show which devices and the number of devices which have been disabled. Press one of the buttons to display detailed information for a particular category

Faults


Enter Supervisor Mode Passcode and select “Faults” tab.



Enable/Disable (others Menu)


To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the passcode.

Enter the Supervisor Mode passcode and select the “Others” tab.





Panel Controls and Indicators

Enable/Disable




The Enable/Disable feature allows the operator to disable part or a whole system by the sub menus shown on the left.




Print (function not available)

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the passcode.

Enter the Supervisor Mode and Select the "Others" Tab. Press "Print"



Select the Information You wish to Print from the Buttons Listed.




Panel Controls and Indicators

Lamp Test

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the passcode.


Enter the Supervisor Mode and Select the "Others" Tab. Press "Lamp Test"




Viewing Events

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the passcode.

Enter the Supervisor Mode Passcode. Select the “Others” tab and press View Log.



Use the scroll bar to view the list of upto 1000 events.





The Panel event log stores up to 1000 events including, fires, faults, and address changes. Once the maximum 1000 events has been reached Panel will automatically overwrite the oldest event every time a new event is stored. The event log can only be reset by an approved service engineer.

Panel Controls and Indicators

Send Log to PC

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the passcode.



Enter the Supervisor Mode and Select the "Others" Tab. Press Send Log to PC.




Erase Log

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the service passcode.

Enter the Service Mode and Select Commission.



Select "Erase Log and Reset" from the Configure Menu Screen.



Panel Controls and Indicators

System Details

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the service passcode.

Enter the Service Mode and Select Commission, then Press "System Details"

Service			Mute Buzzer	Reset
<div style="border: 1px solid black; padding: 10px; margin: 0 auto; width: 80%;"> <div style="background-color: black; color: white; text-align: center; padding: 5px; margin-bottom: 10px;">Commission</div> <div style="border: 1px solid black; text-align: center; padding: 5px; margin: 0 auto; width: 60%;">Configure</div> </div>				


Service	Exit		Mute Buzzer	Reset
Load CDR from Laptop		Repeater Mode		
Download CDR to Laptop		Printer Settings		
Erase Log		Change Panel Number		
System Detail		Number of Panels in Network		
Load logo from PC		Screen Cover		

Service FRE off	Print	Exit		Reset
Program		V0.00.15		
Program Data		09-Mar-2004		
Program Checksum		0xAA95524		
CDR		V0.5		
CDR Checksum		0xF7D95E		
Loop Controller 1		V0.0.0		
Loop Controller 2		V0.0.0		
Panel Number		0		
Total Panels		1		
Total Zones		4		



Load Logo from PC

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the service passcode.

Enter the Service Mode and Select Commission.



Select "Load logo from PC" from the Configure Menu Screen.





Panel Controls and Indicators


Repeater Mode

The Repeater can be set as active or passive. Unlike the active repeater, the passive repeater will only display information, no action from the repeater is transferred to the network.

Enter the Service Mode and Select Commission.



Press "Repeater Mode"






Select "Active" for an active repeater or "Passive" for a passive repeater

Printer Settings

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the service passcode.

Enter the Service Mode and Select Commission then press “Printer settings”.



Panel Controls and Indicators

Change Panel Number

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the service passcode.

Enter the Service Mode and Select Commission then press "Change Panel Number"

Service			Mute Buzzer	Reset
<div style="border: 1px solid black; width: 100px; height: 20px; margin: 10px auto; background-color: black; color: white; display: flex; align-items: center; justify-content: center;">Commission</div> <div style="border: 1px solid black; width: 150px; height: 25px; margin: 10px auto; display: flex; align-items: center; justify-content: center;">Configure</div>				

Service	Exit		Mute Buzzer	Reset
Load CDR from Laptop		Repeater Mode		
Download CDR to Laptop		Printer Settings		
Erase Log		Change Panel Number		
System Detail		Number of Panels in Network		
Load logo from PC		Screen Cover		

Change Panel Number 0	1	2	3
	4	5	6
	7	8	9
	ok	0	←
<div style="border: 1px solid black; padding: 5px; display: inline-block;">Cancel</div>			

Number of Panels in Network

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the service passcode.

Enter the Service Mode and Select Commission then press “Number of Panels in Network”

Service			Mute Buzzer	Reset
<div style="border: 1px solid black; padding: 10px; margin: 10px auto; width: 80%;"> <div style="background-color: black; color: white; text-align: center; padding: 5px; margin-bottom: 10px;">Commission</div> <div style="border: 1px solid black; text-align: center; padding: 5px; margin-bottom: 10px;">Configure</div> </div>				
Service	Exit		Mute Buzzer	Reset
Load CDR from Laptop		Repeater Mode		
Download CDR to Laptop		Printer Settings		
Erase Log		Change Panel Number		
System Detail		Number of Panels in Network		
Load logo from PC		Screen Cover		
Change Panel Number		1	2	3
0		4	5	6
		7	8	9
Cancel		ok	0	←

Panel Controls and Indicators

Change Date/Time

Enter the Service Mode and Select Configure. Select Change Date/Time.

Service			Mute Buzzer	Reset
<div style="border: 1px solid black; width: 200px; margin: 10px auto; padding: 5px;">Commission</div> <div style="background-color: black; color: white; width: 200px; margin: 10px auto; padding: 5px; text-align: center;">Configure</div>				

Service	Exit		Mute Buzzer	Reset
Change Date/Time		Add/Delete Zone		
Change Password		Network		
Relay Control		Language		
Programmable Input		Network Protocol		
		Power Supply		

Set the Time Using the Buttons Shown Below.

Service	Ok	Cancel		Reset
Current Time: 10:16:12		+1 Hour	+10 Mins	+1 Mins
		-1 Hour	-10 Mins	-1 Mins
BST On Current Date: Wednesday dd-mmm-yyyy		+1 Day	+1 Month	+1 Year
		-1 Day	-1 Month	-1 Year

Change Panel Text

Enter the Service Mode and Select Configure. Select "Change Text"

Service	Exit		Mute Buzzer	Reset
Change Date/Time			Add/Delete Zone	
Change Text			Network	
Configure Zones			Language	
Change Password			Network Protocol	
Relay Control			Power Supply	
Programmable Input				

Press "Change Panel Text"

Service	Exit		Mute Buzzer	Reset
<div style="border: 1px solid black; padding: 10px; width: fit-content; margin: 0 auto;">Change Panel Text</div>				

Correct Panel Text										
CF1100.....										←
1	2	3	4	5	6	7	8	9	0	
Q	W	E	R	T	Y	U	I	O	P	
	A	S	D	F	G	H	J	K	L	
CAPS	Z	X	C	V	B	N	M	,	.	
OTHER		SPACE				OK		CANCEL		

Panel Controls and Indicators


Change Passcode

Enter the Service Mode and Select Configure. Select "Change User Code"

Service	Exit		Mute Buzzer	Reset
Change Date/Time	Add/Delete Zone			
Change Text	Network			
Configure Zones	Language			
Change Password	Network Protocol			
Relay Control	Power Supply			
Programmable Input				



Please enter Passcode:	1	2	3
.....			
New Code:	4	5	6
.....			
Verify New Code:	7	8	9
.....			
<input type="button" value="Cancel"/>	ok	0	←



Relay Control

The repeater is equipped with 2 programable relays configured as volt free contact. Enter the Service Mode and Select Configure. Select "Relay Control"

Service	Exit		Mute Buzzer	Reset
Change Date/Time		Add/Delete Zone		
Change Text		Network		
Configure Zones		Language		
Change Password		Network Protocol		
Relay Control		Power Supply		
Programmable Input				

Select the type of relay either "Aux Relay" or "Fault Relay"

Service	Exit		Mute Buzzer	Reset
<div style="background-color: black; color: white; padding: 5px; width: 150px; margin: 0 auto; display: inline-block;">Aux Relay</div> <div style="border: 1px solid black; padding: 5px; width: 150px; margin: 10px auto; display: inline-block;">Fault Relay</div>				

Service	Exit		Mute Buzzer	Reset
<div style="border: 1px solid black; padding: 5px; width: 150px; margin: 0 auto; display: inline-block;">Aux Relay</div> <div style="background-color: black; color: white; padding: 5px; width: 150px; margin: 10px auto; display: inline-block;">Fault Relay</div>				

Select the desired mode

Service	Exit		Mute Buzzer	Reset
On Fire				
On Pre-Alarm				
On Fault				
On Test				
On Disablement				
Not Required				

Panel Controls and Indicators

Programmable Input

The Repeater is equipped with a programmable input which can operate across the network if the repeater is programmed as active.

Enter the Service Mode and Select Configure. Select “Programmable Input”

Service	Exit		Mute Buzzer	Reset
Change Date/Time			Add/Delete Zone	
Change Text			Network	
Configure Zones			Language	
Change Password			Network Protocol	
Relay Control			Power Supply	
Programmable Input				

Select Zone into which device will be added

Service	Exit		Mute Buzzer	Reset
Reset			Fire	
Evacuate			Pre-Alarm	
Silence			Fault	
Not Required			Prog Input Text	

Select the mode of operation from the menu

Network

Enter the Service Mode and Select Configure. Select "Network"; This menu defines whether messages are broadcast across the network or remain local.

Service	Exit		Mute Buzzer	Reset
Change Date/Time		Add/Delete Zone		
Change Text		Network		
Configure Zones		Language		
Change Password		Network Protocol		
Relay Control		Power Supply		
Programmable Input				

Select the specific required . E.g "Reset"

Service	Exit	Receive message over network
Reset		Network
Evacuate		Network
Silence		Network
Fire		Network
Fault		Network
Pre-Alarm		Network

Select if Network is required to be on/off





Service	Exit	Receive message over network
Reset		Not Required
Evacuate		Network
Silence		Network
Fire		Network
Fault		Network
Pre-Alarm		Network

Panel Controls and Indicators

Language

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the service passcode.

Enter the Service Mode and Select Configure.



Select "Language" from the Configure Menu Screen.

Then press select required language from the 3 available pages.

Network Protocol

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the service passcode.

Enter the Service Mode and Select Configure.

Service	Exit		Mute Buzzer	Reset
Change Date/Time			Add/Delete Zone	
Change Text			Network	
Configure Zones			Language	
Change Password			Network Protocol	
Relay Control			Power Supply	
Programmable Input				

Service	Exit			Reset
<div data-bbox="465 1093 762 1157" style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;">Network Protocol V1</div> <div data-bbox="465 1220 762 1284" style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;">Network Protocol V2</div>				

Panel Controls and Indicators

Power Supply

To activate the touch screen, touch the top left corner of the screen until the screen illuminates. To enter the supervisor mode touch the supervisor button and enter the service passcode.

Enter the Service Mode and Select Configure.

Service	Exit		Mute Buzzer	Reset
Change Date/Time			Add/Delete Zone	
Change Text			Network	
Configure Zones			Language	
Change Password			Network Protocol	
Relay Control			Power Supply	
Programmable Input				

Service	Exit			Reset
<div data-bbox="372 1102 678 1169" style="border: 1px solid black; padding: 5px; margin: 10px auto; width: 250px;">Internal Power</div> <div data-bbox="372 1233 678 1300" style="border: 1px solid black; padding: 5px; margin: 10px auto; width: 250px;">External Power</div>				

Password Protection

Please enter Passcode	1	2	3
	4	5	6
	7	8	9
	ok	0	←

The system has password protection which restricts access to the DISABLE Menu and to TEST/COMMISSIONING MODE. The password is a four digit code and the default number is 2214. The password entry screen is accessed via the supervisor mode button. Press supervisor mode and the password entry screen will be displayed, type in the passcode and press Ok. If the wrong password is entered three times further access to the system is denied.



Powering Business Worldwide

Eaton Electrical Systems Ltd.

Wheatley Hall Road
Doncaster
South Yorkshire
DN2 4NB

Eaton

EMEA Headquarters
Route de la Longeraie 7
1110 Morges, Switzerland
Eaton.eu

© 2019 Eaton
All Rights Reserved
Publication No. 25-16315-A
January 2019

Eaton is a registered trademark.

All trademarks are property
of their respective owners.