JOCKEY Touch™

XTJP
XTJY

NOTE: To select a proper part number - refer to the current Eaton Pricing Guidelines for available combinations.

Amperage Range

Three Phase

G01	0.6-1.0
G02	1.1-1.6
G03	1.7-2.5
G04	2.6-4.0
G05	4.1-6.3
G06	6.4-10.0
G07	10.1-16.0
G08	16.1-20.0
G09	20.1-25.0
G10	25.1-32.0
G11	32.1-40.0
G12	40.1-50.0
G13	50.1-65.0

Single Phase

G14	2.6-4.0
G15	4.1-6.3
G16	6.4-10.0
G17	10.1-16.0
G18	16.1-20.0
G19	20.1-25.0
G20	25.1-32.0
G21	32.1-40.0
G22	40.1-50.0
G23	50.1-65.0

Horsepower (KW) *

15	(11)
20	(15)
25	(18.6)
30	(22)
40	(30)
50	(37)

Voltage *

A =	208V - 60HZ
B =	240V - 60HZ
C =	380V - 50HZ
D =	480V - 60HZ
E =	600V - 60HZ
F =	415V - 50HZ
H =	380V - 60HZ
J =	400V - 50HZ
K =	400V - 60HZ

* NOTE: Voltage letter designations are only used when a Horsepower (KW) is selected.

Languages

L1 =	English
L2 =	French
L5 =	Spanish
L6 =	Portuguese
L11 =	Turkish

Other Languages available. Consult factory for details.

Options

C1	Extra Contacts "Pump Run"
C2	Extra Contacts "AC Power Failure"
CX	Extra Contacts (One Form-C; Specify Function)
E1	NEMA 3R - Raintight Enclosure
E2	NEMA 4 - Watertight Enclosure
E3	NEMA 12 - Industrial Dust Tight Enclosure
E5	NEMA 4X - 304 Stainless Steel Enclosure
E8	Tropicalization
E9	NEMA 4X - Painted Steel
E10	NEMA 4X - 316 Stainless Steel Enclosure
EX	Export Crating
FTS	Extra Contacts "Fail to Start"
LX	Virtual LED (Specify Description)
POL	"Power-On" Virtual LED
PRL	"Pump Run" Virtual LED
P7	Low Suction Pressure Switch & Alarm Virtual LED
P8	Low Suction Shutdown (Requires P7)
P10	Pressure Transducer - Sea Water Rated
R1	Space Heater (120 / 220V) - Externally Powered
R2	Space Heater c/w Thermostat - Externally Powered
R3	Space Heater c/w Humidistat - Externally Powered
USB	Externally Mounted USB Port