



Powerware®

9390

Seismic Kit

## INSTALLATION INSTRUCTIONS



**NOTE** Refer to the applicable installation and operation manual supplied with the UPS or IDC during the seismic kit installation.

Seismic Kit Contents	Seismic Side Angle	M8 × 20 Hex Bolt
80–160 kVA UPS; 160 kVA IDC	2	10
80 kVA IDC	2	18

To install the seismic kit, perform the procedures in the following steps:

1. Mechanically install the UPS or IDC according to the instructions in the applicable installation and operation manual.



**NOTE** For UPS units with the optional UPS Sidecar, the left side bracket is part number 157605513 and the right side bracket is part number 157605589. For UPS units without the Sidecar, both left and right brackets are part number 157605513.

2. Remove the side angles from the kit and secure one angle to the left and right sides of the cabinet with five M8 bolts from the kit.
3. **For 80 kVA IDC only** – Replace the four bolts securing each front and rear shipping bracket to the cabinet with the M8 bolts from the kit.
4. Secure the cabinet to the floor with contractor-supplied hardware. Refer to the seismic dimensional drawing in Appendix A of the applicable manual for mounting hole dimensions.

164201585 Rev A