


# TO ADD SWD DEVICES TO CODESYS V3

(May 2015 – Hale)

First unzip Device Description file “**SWD-M12\_Step1\_3\_XV100\_XC152\_CODESYS-3**” to folder (these have “.devdesc” extensions). Unzip Password=“swd”:

Step 1) Select “Tools”

Step 2) Select “Device Repository”



Step 3) Select “Fieldbuses”

Step 4) Select “SmartWire-DT”

Step 5) Select “SWD Module”

Step 6) Select “Install Button”

Step 7) Browse to folder containing the unzipped Device Description files

Step 8) Select the files that you want to install/add

Step 9) Select “Open”

Done

