

MP2 Surface - Fixing Bracket

1 Remove luminaire front and contents within. Drill rear panel at the locations shown to 6mm diameter.

2 Insert upper bracket vertically into cutout in ceiling panel and locate (as below).
Ensure small locating tabs protrude through cutout to secure bracket in place

Reverse View

3 Screw in lower bracket but do not tighten until both lower and upper parts are parallel with the side of the ceiling tile. Once parallel, tighten screws. Ensure screws are not over-tightened and damage ceiling tile.

4 Locate Micropoint rear panel onto studs on lower bracket. Secure in place with M5 nuts. Re-assemble fitting and refer to instruction K940 (supplied with fitting)

MP2 Surface - Fixing Bracket

1 Remove luminaire front and contents within. Drill rear panel at the locations shown to 6mm diameter.

2 Insert upper bracket vertically into cutout in ceiling panel and locate (as below).
Ensure small locating tabs protrude through cutout to secure bracket in place

Reverse View

3 Screw in lower bracket but do not tighten until both lower and upper parts are parallel with the side of the ceiling tile. Once parallel, tighten screws. Ensure screws are not over-tightened and damage ceiling tile.

4 Locate Micropoint rear panel onto studs on lower bracket. Secure in place with M5 nuts. Re-assemble fitting and refer to instruction K940 (supplied with fitting)