CPU Docker Rack Mount Conversion

Item Numbers

17601204, PCPRKIT20, PCPRKIT28

Tools Required

- Phillips head screwdriver (not supplied)

1. Remove the Roll-Out Tray and slides from the Docker as shown in figure 1.
2. Install upper channels on both sides of Docker with #89957 screws as shown in figure 1.
3. Loosely install the #88114 screws, #87858 lock washers and #87382 T-handles to the four Rack Mount Rails as shown in figure 2.
4. Install the Rack Mount Rails inside the Docker as shown in figure 3. Slide the screws behind the slots and move each rail to their appropriate location and tighten the T-handles.

Note; Item 17601204 **Does Not Require** the upper channels

Docker

#89957 Screws

Upper Channel

Roll-Out Tray and slides

Figure 1

#8814 Screw

#87858 Lock washer

#87382 T-handle

Rack mount rail

Figure 2

Rack Mount Rail

Slot

T-handle

Figure 3

F·A·T·N
Powering Business Worldwide