




NEW! xComfort rockers with symbols

Would you like to use xComfort universal 55x55 mm pushbuttons to:

- Operate the entire house with one main switch
- Set the home in night or morning mode
- Or what about any kind of mood light for example TV mode?

There is now a range of eye catching symbols to be used for xComfort universal pushbuttons for an even more clear and intuitive operation. Already installed pushbuttons can be upgraded very easily, by just replacing the rockers without the use of special tools. Everyone can do it!



- **CWIZ-01/71 (196842)**
pure white, gloss finish, single rocker «home-away»



- **CWIZ-02/81 (196843)**
pure white, gloss finish, double rocker «home-away/morning-evening»



- **CWIZ-02/91 (196844)**
pure white, gloss finish, double rocker «dinner-mood/morning-evening»

EATON

Powering Business Worldwide

LiveSmart

www.eaton.com/xcomfort