


RS Anti-tip stabilizer bracket

The anti-tip stabilizer bracket attaches to outside of enclosure, using M6 screws. The bracket adds stability to enclosure when using roll out shelves or equipment.

i NOTE

The enclosure will not meet International Building Codes (IBC) anchorage requirements, when using this bracket alone. Please refer to Eaton Support for more on appropriate anchoring information.



Stabilizer kit RSANTXX includes:

- A** One stabilizer bracket (600 mm or 800 mm)
- B** Four M6 Phillips head crews

Tools needed to install: Phillips head screw driver.

! WARNING

Never extend more than one shelf or piece of rollout equipment, even with stabilizer bracket assembled to the enclosure. **Failure to follow this warning could result in the possibility of the enclosure tipping, causing serious injury or property damage.**

DISCLAIMER OF WARRANTIES AND LIMITATION OF LIABILITY

The information, recommendations, descriptions and safety notations in this document are based on Eaton Corporation's ("Eaton") experience and judgment and may not cover all contingencies. If further information is required, an Eaton sales office should be consulted. Sale of the product shown in this literature is subject to the terms and conditions outlined in appropriate Eaton selling policies or other contractual agreement between Eaton and the purchaser.

THERE ARE NO UNDERSTANDINGS, AGREEMENTS, WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, OTHER THAN THOSE SPECIFICALLY SET OUT IN ANY EXISTING CONTRACT BETWEEN THE PARTIES. ANY SUCH CONTRACT STATES THE ENTIRE OBLIGATION OF EATON. THE CONTENTS OF THIS DOCUMENT SHALL NOT BECOME PART OF OR MODIFY ANY CONTRACT BETWEEN THE PARTIES.

In no event will Eaton be responsible to the purchaser or user in contract, in tort (including negligence), strict liability or otherwise for any special, indirect, incidental or consequential damage or loss whatsoever, including but not limited to damage or loss of use of equipment, plant or power system, cost of capital, loss of power, additional expenses in the use of existing power facilities, or claims against the purchaser or user by its customers resulting from the use of the information, recommendations and descriptions contained herein. The information contained in this manual is subject to change without notice.



Eaton
1000 Eaton Boulevard
Cleveland, OH 44122
United States
Eaton.com

© 2016 Eaton
All Rights Reserved
Printed in USA
Publication No. IL159026EN
June 2016

Eaton is a registered trademark.

All trademarks are property of their respective owners.

Follow us on social media to get the latest product and support information.

