


Eaton® Power Xpert® Gateway Minislot (PXGMS) UPS Card

Quick Start Instructions



Package Contents

- Power Xpert Gateway Minislot (PXGMS) UPS Card
- USB Cable
- Quick Start Instructions



Powering Business Worldwide

Help Desk Numbers

United States	1-800-356-5737 or 1-800-843-9433
Canada	1-800-461-9166 ext 260
All Other Countries	Call your local service representative
Web Site	www.eaton.com/pxgms

NOTE: On the Web site opening page, click **Support** and select the Customer Service link for more information.

Eaton, Power Xpert, and PredictPulse are registered trademarks of Eaton or its subsidiaries and affiliates. Google Chrome is a trademark of Google Inc. Linux is a registered trademark of Linus Torvalds. Microsoft, Internet Explorer, and Windows are registered trademarks of Microsoft Corporation in the United States and in other countries. Mozilla and Firefox are registered trademarks of the Mozilla Foundation. All other trademarks are property of their respective companies.

©Copyright 2015–2019 Eaton, Raleigh, NC, USA. All rights reserved. No part of this document may be reproduced in any way without the express written approval of Eaton Corporation.

TABLE OF CONTENTS

Section 1 Installation Checklist	2
Section 2 Install the Card	3
Section 3 Connect the Card to the Computer	5
Section 4 Install the USB Driver Software	7
Section 5 Obtain a DHCP-Assigned IP Address	11
Section 6 Assign an IP Address Manually	15
Section 7 Enable Browser Compatibility Mode	18
Section 8 Register a Predict <i>Pulse</i> Subscription.....	19

Section 1 Installation Checklist

1. Verify that the following items are available:
 - Power Xpert Gateway Minislot (PXGMS) UPS Card package contents (card, cable, Quick Start Instructions)
 - Phillips® screwdriver
 - Available USB port on a computer running Microsoft® Windows®
 - Web browser (Microsoft Internet Explorer® version 11.0 and higher, Mozilla® Firefox®, or Google Chrome™ are recommended)
2. If you are going to use Dynamic Host Configuration Protocol (DHCP), provide your local network administrator with the card's MAC address. The MAC address is located on either the shipping box label or the label on this card.
 - MAC Address _____
3. If you are not going to use DHCP to provide any of the settings listed below, contact your local network administrator for the settings.

In the table below, check the **DHCP** check box or enter the values for manual configuration. This data is referenced later in the procedure.

Item	DHCP*	Manual Configuration
IPv4	<input type="checkbox"/>	Card IP Address: _____ Netmask: _____ Gateway: _____
DNS – Name Servers	<input type="checkbox"/>	Name Server #1: _____ Name Server #2: _____ Name Server #3: _____
DNS – Domain	<input type="checkbox"/>	Domain: _____

* The network administrator normally sets up the DHCP server to provide a static IP address each time the card makes a DHCP request.

4. If you need e-mail functionality, obtain the SMTP mail server's IP address or host name. If using the SMTP host name, verify that you also have the Name Server IP address (see Step 3).
 - SMTP (mail server) IP Address
or Host Name _____

Section 2 Install the Card

NOTE 1 The hot-swappable PXGMS card can be installed without turning off the UPS or disconnecting the load.

NOTE 2 If your UPS is a 93PM, there may be a metal strip that prevents you from installing the PXGMS card. If so, locate the metal strip bolted to the top of the UPS. Remove the three bolts that attach the metal strip. Then, follow the procedure to install the PXGMS card.

To install the PXGMS card:

1. On the PXGMS card, verify that all six DIP switches are in the OFF position (see Figure 1).




Figure 1. Verify DIP Switches are OFF

2. If not already done, record the MAC address from either the shipping box label or the label on this card for future reference (see the "Installation Checklist" on page 2).
3. Remove the minislot cover from the UPS. Retain the screws.

NOTE If another card is already installed with an attached communication cable, disconnect the cable and then remove the card.

4. To prevent electrostatic discharge (ESD), place one hand on a metal surface, such as the UPS rear panel.

- Slide the card into the open slot and secure it with the screws removed in Step 2 (see Figure 2).




Figure 2. Secure the PXGMS Card

- From your laptop, go to www.eaton.com/pxgms.
- On the Resources tab, click the **Software, Firmware, and Applications** link to download the **Power Xpert Gateway USB Signed Windows Device Driver**.
- Save the driver configuration file (eaton-pxgms-firmware.zip) to the C: drive using the default location or a folder you select. Note the path of the downloaded file on your computer. (Never download the file to your desktop.)

Section 3 Connect the Card to the Computer

To connect the card to the computer:

1. Plug the small connector at the end of the supplied USB configuration cable into the setup port on the card (see Figure 3).




Figure 3. Install the USB Cable

2. Plug the other end of the USB cable into the USB port on the computer. The Windows operating system detects new hardware.

NOTE 1 If a message indicates that the device driver software was not successfully installed, click **Ignore**.

NOTE 2 You may see a pop-up message window that shows "Found new hardware." This indicates that the hardware installed successfully.

3. Connect an active Ethernet cable (not supplied) to the Ethernet 10/100 connector on the PXGMS card (see Figure 4).




Figure 4. Install the Ethernet Cable

4. Wait for the power light and status light on the installed card to illuminate. This takes about two minutes.
5. Open a Web browser and type the default IP address (**https://169.254.0.101** for firmware 2.6.0 or later, **http://192.168.200.101** for earlier firmware versions).
6. Did the Power Xpert Gateway software open to the PXGMS page?
 - If yes, the driver has already been installed automatically. Either verify the IP address assigned through DHCP or manually enter a static (fixed) IP address for the card's network connection:
 - a. To verify the DHCP-assigned IP address, go to page 13.
 - b. To manually enter a fixed IP address, go to page 16.
 - If no, the driver has not been installed. Go to the next section, "Install the USB Driver Software" on page 7 in order to confirm that you have the most current USB Driver software. If not, you need to install or update the USB Driver software.

Section 4 Install the USB Driver Software

The steps you use to install the driver software depend on your operating system (OS). This procedure provides instructions for installing driver software on a Windows 7 OS.

NOTE 1 Windows 8 steps are basically the same as Windows 7, although the dialog displays may differ somewhat.

NOTE 2 The PXGMS and PXGX UPS cards use the same driver.

NOTE 3 You can use either the Device Manager path or the Devices and Printers path to browse for the driver software and install it. This procedure uses the Device Manager.

To install the driver from the **Device Manager**:

1. Click **Start** in the Start bar. Type Device in the search box.
2. Select **Device Manager** from the list above the search box. The Device Manager opens.
3. Locate **RNDIS/Ethernet Gadget** under either **Other Devices** or **Network Adapters** (see Figure 5).
 - If you do not see RNDIS/Ethernet Gadget in either list, you do not have a cable connected to the card. Connect the computer to the card. Go back to Step 1.
 - If RNDIS/Ethernet Gadget is listed under Other Devices, the driver is not installed. Go to Step 4.
 - If RNDIS/Ethernet Gadget is listed under Network Adapters, a driver is installed already, but you it may not be the most up to date driver. Go to Step 4.




Figure 5. Device Manager Window

4. Right-click RNDIS/Ethernet Gadget to display the menu and select **Update Driver Software**.
 - If a pop-up message displays, “The best driver is already installed,” click **Close** and go to Step 10.
 - Otherwise, go to Step 5.
5. Select **Browse my computer for driver software** (see Figure 6). Click **Next**. The next page displays.




Figure 6. Update Driver Software Window – Search Method

6. Click **Browse**. The “Browse for Folder” dialog displays. Select the folder that contains drivers for your hardware. Click **OK**. The “Browse for driver software on your computer” page displays.
7. The path to the powerxpert.inf file displays in the **Search for driver software in this location** box. Click **Browse** and navigate to the powerxpert.inf file you already downloaded. Select the file and click **Next** (see Figure 7).
 - If a pop-up message displays, “The best driver is already installed,” click **Close** and go to Step 10.
 - Otherwise, the software begins to install.




Figure 7. Update Driver Software Window – Browse for Driver Software

8. When the driver software is updated successfully, the message “Windows has successfully updated your driver software” displays (see Figure 8).




Figure 8. Update Driver Software Window – Update Successful

9. Click **Close**.
10. Either obtain the DHCP-assigned IP address or manually enter a fixed IP address:
 - To obtain the IP address assigned through DHCP, continue to “Obtain a DHCP-Assigned IP Address” on page 11.
 - To manually enter a static (fixed) IP address for the card’s network connection, continue to “Assign an IP Address Manually” on page 15.

NOTE By default, the PXGMS card requests an IP address through DHCP when connected to a network.

Section 5 Obtain a DHCP-Assigned IP Address

To obtain the IP address through DHCP:

1. Ensure the PXGMS card is still connected to the computer over the USB cable. Also ensure that the network cable is connected from the PXGMS card Ethernet port to the network connection.
 2. If your Web browser already open to the default IP address, go to Step 3. Otherwise, perform the following:
 - Open your Web browser.
 - Enter: **https://169.254.0.101** for firmware 2.6.0 or later, **http://192.168.200.101** for earlier firmware versions.
 - Log on as administrator. The default username and default password are "admin." The PXGMS card Web page displays.
- NOTE** If the system is unresponsive and you cannot make any selections, the browser may not be running in compatibility mode. To enable compatibility mode, go to "Enable Browser Compatibility Mode" on page 18.
3. Select **Network** from the Configuration menu. The **Network** page displays (see Figure 9).




Figure 9. PXGMS Card Network Page

4. Under IPv4, the **Automatic Configuration: DHCP Enabled** setting checkbox should be enabled by default. Make sure the checkbox is checked (enabled) before continuing.
5. Scroll down to **Name Service** and expand the selection to update the next two DHCP settings (see Figure 10):
 - Check the checkbox (enable) for **Use DHCP (when enabled) to get name services**.
 - Check the checkbox (enable) for **Use DHCP (when enabled) to get domain name**.

6. Click **Apply**.




Figure 10. Name Services Settings

7. Select **Yes** for the message, “**Do you want to save the Network Configuration?**”
8. Wait for approximately two minutes for the card to reboot. Initially, all lights are lit. You will know the card has finished rebooting when only the top light (Status) and the bottom light (Power) remain lit.

9. Open a browser and enter the default IP address (**https://169.254.0.101** for firmware 2.6.0 or later, **http://192.168.200.101** for earlier firmware versions).
10. When prompted, log on as administrator. The default username and default password are "admin." The PXGMS card Web page displays.
11. Click **Network** in the menu list.
12. Does the DHCP-assigned IP address display?
 - If yes, uncheck (disable) the DHCP Enabled box and select **Apply**.

NOTE At this point, the DHCP address is saved as a static IP address.

- If no, go to "Assign an IP Address Manually" on page 15 to manually obtain a static IP address for the PXGMS card.

NOTE For detailed information, refer to the user's guide for the *Eaton Power Xpert Gateway Minislot (PXGMS) User's Guide*, which is available through a link on the Documentation tab on the PXGMS product Web page.

Section 6 Assign an IP Address Manually

To manually enter a static (fixed) IP address for the card:

1. Ensure the PXGMS card is still connected over the USB cable and the network cable is connected from the PXGMS card Ethernet port to the network connection.
2. If your Web browser already open, go to Step 3. Otherwise, perform the following:
 - Open your Web browser.
 - Enter: **https://169.254.0.101** for firmware 2.6.0 or later, **http://192.168.200.101** for earlier firmware versions.
 - Log on as administrator. The default username and default password are "admin." The PXGMS card Web page displays.
 - Go to Step 3.

NOTE If the system is unresponsive and you cannot make any selections, the browser may not be running in compatibility mode. To enable compatibility mode, go to "Enable Browser Compatibility Mode" on page 18.

3. Select **Network** from the Configuration menu. The Network page displays.




Figure 11. Disable DHCP Setting

4. Uncheck the **DHCP Enabled** checkbox to disable DHCP and allow you to manually configure the IP address (see Figure 11).
5. Refer to the "Installation Checklist" on page 2 in this book. Enter the IP address, Netmask, and Gateway addresses in the **IPv4 > Manual Configuration** section.
6. Click **Apply**, then click **OK** to confirm.
7. **Optional.** If you are using a host name, or host names, for controlling access to the card:
 - Type the server IP address in the **Name Server** box. (Up to three IP addresses can be entered.)
 - Click **Apply**. Click **OK** to confirm.

8. Open a browser and enter the fixed (static) IP address.
9. Log on as administrator. The default username and default password are "admin." When the PXGMS card Web page displays, you know the fixed IP Address is working.

NOTE For detailed information, refer to the user's guide for the *Eaton Power Xpert Gateway Minislot (PXGMS) User's Guide*, which is available through a link on the Documentation tab on the PXGMS product Web page.

Section 7 Enable Browser Compatibility Mode

Browser compatibility allows Web pages designed for older versions to display properly. If data does not display properly on your PXGMS card Web page, the browser compatibility mode should be enabled.

To enable the compatibility mode:

1. Open your Web browser.
2. In the Menu bar select **Tools > Compatibility View Settings**. The Compatibility View Settings window opens (see Figure 12).




Figure 12. Compatibility View Settings Window

3. Under “Add this website:” type the IP address of the PXGMS card and click **Add**.

NOTE Close and re-open your browser so that the changes take effect.

Section 8 Register a PredictPulse Subscription

PredictPulse™ is a remote monitoring and management subscription service that collects and analyzes data from connected power infrastructure devices, providing Eaton with the insight needed to make recommendations and take action on your behalf. This service has limited availability outside of the United States. For more information go to www.eaton.com/predictpulse.

NOTE Contact your Eaton service representative for availability of PredictPulse in your region.

Use either the universal PredictPulse Subscription Wizard or the PXGMS PredictPulse setup feature to configure your profile and register the Eaton UPS devices monitored by PredictPulse.

The universal PredictPulse Wizard can be downloaded from the PredictPulse web site to begin your subscription registration. Using this method, you can register devices individually or as a group.

However, the latest firmware for the PXGMS and PXGX UPS cards contain a PredictPulse activation set-up feature. As long as these cards are on your network, you can quickly activate subscriptions without the wizard and save time.

To begin registering with the set-up feature, follow this procedure. An e-mail with additional instructions to finish registering and configuring your card is automatically sent to the provided e-mail address.

To register an installed PXGMS card for PredictPulse:

1. Locate the PredictPulse selection under the Configuration menu on the Power Xpert Gateway window.

NOTE 1 If there isn't a PredictPulse selection, either update your firmware or download the universal PredictPulse Wizard from www.eaton.com/predictpulse and follow the instructions in the Wizard and subsequent e-mail messages.

NOTE 2 Refer to the *Eaton Power Xpert Gateway Minislot (PXGMS) User's Guide* for more information.

2. On the Power Xpert Gateway window, select **Configuration > PredictPulse** (see Figure 13).




Figure 13. Registering a PredictPulse Subscription

3. Confirm that the checkbox for "Enable PredictPulse" is checked (enabled).
4. Complete the following fields:
 - **Contact Name:** First and last name of the contact person.
 - **Contact Email:** E-mail address of the contact person for event data.
 - **Confirm Email:** E-mail address again for confirmation.
 - **Country:** Country where the main contact resides.
5. Click **Apply** to save.
6. Click **OK** in response to the message, "Are you sure you want to apply settings and send registration email?"

7. A progress message box informs you that registration is in progress. When the first step in registration completes successfully, the contact person identified on the *PredictPulse* settings page receives an e-mail with additional instructions (see Figure 14). Registration should be completed on the Eaton portal by this contact person.




Figure 14. Confirmation Message



P-164000208 3