



Eaton 9PX 3:1 6000 for Pf= 0.9 loads (100% = 6000 VA / 5400 W)  
Standard configuration = 1 Power Module + 1 EBM




Eaton 9PX 3:1 6000 + 1 to 5 EBM for Pf= 0.9 loads (100% = 6000 VA / 5400 W)  
**Standard configuration = 1 Power Module + 1 EBM**




actual runtime may vary from +/- 15% around these typical values

Eaton 9PX 3:1 6000 + 6 to 11 EBM for Pf= 0.9 loads (100% = 6000 VA / 5400 W)  
**Standard configuration = 1 Power Module + 1 EBM**  
**Supercharge r is recommended**




actual runtime may vary from +/- 15% around these typical values

Eaton 9PX 3:1 8000 for Pf= 0.9 loads (100% = 8000 VA / 7200 W)  
Standard configuration = 1 Power Module + 1 EBM



Eaton 9PX 3:1 8000 + 1 to 5 Add EBM for Pf= 0.9 loads (100% = 8000 VA / 7200 W)  
 Standard configuration = 1 Power Module + 1 EBM




actual runtime may vary from +/- 15% around these typical values

Eaton 9PX 3:1 8000 + 6 to 11 Add EBM for Pf= 0.9 loads (100% = 8000 VA / 7200 W)


Standard configuration = 1 Power Module + 1 EBM

Supercharger is recommended




actual runtime may vary from +/- 15% around these typical values

Eaton 9PX 3:1 11000 for Pf= 0.9 loads (100% = 11000 VA / 10000 W)  
Standard configuration = 1 Power Module + 1 EBM



Eaton 9PX 3:1 11000 + 1 to 5 Add EBM for Pf= 0.9 loads (100% = 11000 VA / 10000 W)  
 Standard configuration = 1 Power Module + 1 EBM





Eaton 9PX 3:1 11000 + 6 to 11 Add EBM for Pf= 0.9 loads (100% = 11000 VA / 10000 W)  
 Standard configuration = 1 Power Module + 1 EBM  
 Supercharge r is recommended

