


Corner TechOrganizer

Tools Required

- #33 (.113 dia.) Drill (Jobbers length)
- Electric drill
- 5/32" Allen wrench (provided)
- Phillips head screwdriver
- Plastic mallet



Corner TechOrganizer
Corner TechBench™ Shelf

The **Corner TechOrganizer** can be installed on Linx Worksurfaces or appropriate industrial work benches.

LINX Worksurfaces with full depth uprights are recommended to provide a Workstation/Organizer with greatest stability.

Important Safety Instructions

- * The Organizer must be properly secured to the Work-surface prior to installing of components.
- * Frame load capacity is 300 lbs. (Linx worksurfaces)
400 lbs. (Workbenches).
- * Do not install shelves that are greater than 18" deep.
- * Do not install shelves more than 35" above the Work-surface.

1. Assemble Left hand and Right hand **Organizer frames** to the **Corner post** with the 1/4"-20 x 1-5/8" Button head cap screws provided. See **Figure 1**.




Figure 1.




Powering Business Worldwide

2. With two people, position the TechOrganizer in the desired location on the back of the Worksurface. On a Linx Worksurface, locate the back of the frame .20" from the back edge of the Worksurface. See **Figure 2**.
3. Using the holes in the frame bottom crossbar and the holes in the feet as a template, locate and drill the appropriate quantity of .113 dia. holes .50" deep in the Worksurface. See **Figure 2**.

NOTE: If the feet are not 90° to the frame, tap the ends with a plastic mallet to correct.

4. Attach the frame bottom crossbar to the worksurface using the #10AB x 2.25" Phillips head flat head screws (provided). See **Figure 2**.
5. Attach the feet to the Worksurface using the four #10AB x .75" Phillips pan head screws (provided). See **Figure 2**.



TechOrganizer Phenolic Corner TechBench

TOOLS REQUIRED

- (1) #19 drill bit (not supplied)
- (1) 7/32" drill bit (not supplied)
- (1) Electric drill (not supplied)
- (1) Phillips head screwdriver
- (1) Plastic mallet
- (1) 3/8" wrench


Important Safety Instructions

- * The Organizer must be properly secured to the Work-surface prior to installing of components.
- * Frame load capacity is 400 lbs. (TechBench).
- * Do not install shelves that are greater than 18" deep.
- * Do not install shelves more than 35" above the Work-surface.

1. Position the Corner TechOrganizer in the desired location on the back of the Phenolic worksurface. See figure 1.
2. Using the holes in the frame bottom crossbars as a template, locate and drill the appropriate quantity of .164 dia. holes .650" deep in the worksurface. See figure 1.

NOTE: If the feet are not 90° to the frame, tap the ends with a plastic mallet to correct.

3. Attach the frame bottom crossbars to the worksurface using the #10 x 2.00" phillips flat head screws provided. See figure 1.



Corner TechOrganizer




Figure 1.

4. Using the holes in the feet as a template, locate and drill four .218 dia. holes **thru** the worksurface. Attach the feet to the worksurface using the four #10 x 1.25" phillips pan head machine screws, #10 washers, #10-32 lock nuts and #10-32 acorn nuts provided. See figure 2.




Figure 2

Eaton
1000 Eaton Boulevard
Cleveland, OH 44122
United States
Eaton.com

© 2018 Eaton
All Rights Reserved
Printed in USA
Publication No. IL211020EN 85081
May 2018

Eaton
160 Gold Star Boulevard
Worcester, MA 01606
United States
800-225-7348
508-852-4300
Eaton.com/furniture

Eaton is a registered trademark.

*All trademarks are property of their respective owners.

Follow us on social media to get the latest product and support information.

