Sliding Keyboard/Pedestal Bracket

Overview

- The Sliding Keyboard/Pedestal Brackets are designed to accommodate both 30" (762mm) and 36" (914,4mm) deep worksurfaces.
- They can be used with laminate, phenolic and maple worksurfaces.
- Both units can only be used with 36"" (914,4mm) thru 96" (2438,4mm) Linear TechBenches.
- Each unit is rated for 150 lbs (330,0 kg).
- The Keyboard Bracket has a mounting hole pattern to accept a "KB" Cobra style mounting track.
- The Pedestal Bracket has (2) sets of hole patterns. One hole pattern is for a C38X series Pedestal, the other is for a "KB" Cobra style keyboard track.
- A safety locking feature prevents accidental disengagement on the units.
- A synthetic grease must be applied to both front and rear TechBench™ stiffeners as well as the Sliding Keyboard/Pedestal Bracket assemblies. This will ensure smooth motion of loaded units.
- A knob located on the front of each Sliding keyboard/Pedestal Bracket locks the unit in place during use.




Instruction Sheet **IL211024EN**

Effective May 2018


Tools Required

- %16" Open end wrench
- Remove the two ³/₈" x 1½" long hex head bolts, two Plastic Rollers, Locking Knob and nylon washer from the Sliding Keyboard/Pedestal Bracket assembly. See figure 1. **Do not discard!**
- 2. Apply synthetic grease to entire top and underside of the two flanges as shown in figure 1.

IMPORTANT: Verify that grease has been applied to both front and rear TechBench[™] stiffeners. If grease has not been applied, refer to TechBench[™] manual #91398.



Sliding Keyboard/Pedestal Bracket



3. To install the Sliding Keyboard/Pedestal Bracket assembly to the underside of the TechBench™, align the cut-out in the assembly with the front Stiffener and push the assembly up against the underside of the worksurface. See figure 2.




Figure 2. (Worksurface not shown)

4. Push the assembly toward the rear of the bench to engage the flanges with the front and rear Stiffeners. See figure 3.




Figure 3. (Worksurface not shown)

Instruction Sheet **IL211024EN**

Effective May 2018

- 5. While holding the unit in place, align the two Plastic Rollers (removed in step 1) with the holes in the top of the bracket. See figure 4. The Rollers should be between the worksurface and the bracket.
- 6. Re-install the two Locking Bolts (removed in step 1) into the holes as shown in figure 4. Thread them all the way in and tighten using the %16" wrench.
- 7. Re-install the Locking Knob and 3/8" nylon washer(removed in step 1). **Do not** tighten.




Figure 4. (Worksurface not shown)



1000 Eaton Boulevard Cleveland, OH 44122 United States Eaton.com

© 2018 Eaton All Rights Reserved Printed in USA Publication No. IL211024EN 91647 May 2018 Eaton 160 Gold Star Boulevard Worcester, MA 01606 United States 800-225-7348 508-852-4300 Eaton.com/furniture Eaton is a registered trademark.

*All trademarks are property of their respective owners.

Follow us on social media to get the latest product and support information.









