

**3 Surface Mount Accessory**

All dimensions are in mm

A. Fix Backplate to ceiling, using one of the above methods

B. Hook the Linergy Square onto the backplate. Loosen thumb wheel (DO NOT FULLY REMOVE) slide latch across, ensuring engagement into the housing of the Linergy Square. Once engaged tighten the thumb wheel and wire the fitting.

C. Once wired, dis-engage the latch and offer the Linergy Square up to the back plate. To fix into position, screw two M6 screws (supplied) into the tabs on the housing through into the backplate

**IMPORTANT NOTE:**


- Luminaire battery **MUST NOT** be connected until building has a permanent un-switched live supply.
- Repeated full discharges caused by fully removing power to luminaires with connected batteries (i.e. a nightly building power down prior to hand over) will permanently damage the battery and invalidate any warranty.

**Safe Operation**

1. Check the rating label for voltage and frequency before connecting this luminaire to the electrical supply.
2. Ensure that the mains supply is switched off when working on this luminaire, whether installing or carrying out any other servicing.
3. Do not mount luminaire on or close to readily flammable materials.
4. To prevent damage to driver, do not mix with conventional magnetic ballasts on the same electrical circuit.
5. Where use in more onerous situations is required, e.g. in part-completed buildings before "drying-out" is completed, or areas where ambient temperatures are outside the normal temperature range, then consult our Sales Office.
6. The light output of the product may cause injuries to human eyes in circumstances where the product is viewed directly with unshielded eyes for more than a few seconds.

**Servicing and Disposal**

1. At commissioning and handing over of installation ensure that a copy of these instructions is presented to the authority responsible for the operation and maintenance of the luminaries.
2. Servicing, e.g. cleaning, must only be carried out after the electricity supply has been switched off. It must not be assumed that luminaries with lamps not lit are switched off-always check before servicing.
3. Cleaning should be carried out at regular intervals to ensure that dirt does not accumulate to an extent that will impair the thermal safety or optical performance of the luminaire. Regular cleaning will also ensure that the optical performance of the luminaries is maintained.
4. Avoid touching the LED array surface. To clean - Blow surface with either dry air or nitrogen gas.
5. At the end of life the luminaire is classed as WEEE under directive 2002/96/EC and should be disposed of in accordance with local legislation.



**Eaton**  
Wheatley Hall Road, Doncaster, South Yorkshire, DN2 4NB

**Sales**  
T: +44 (0)1302 303303  
F: +44 (0)1302 367155  
E: sales@cooper-ls.com

**General**  
+44 (0)1302 321541  
+44 (0)1302 303220  
technical@cooper-ls.com

**International Sales**  
+44 (0)1302 303250  
+44 (0)1302 303251  
export@cooper-ls.com

K1081V



# Linergy LED Square

- Product luminaires comply with EN60598 and are suitable for use in normal interior conditions.
- This luminaire has an ambient temperature range of -10°C to 25°C for the non-emergency version
- For Emergency variants - This luminaire has an ambient temperature range of 5 C to 25 C, to ensure the batteries work correctly

**1 Dimensions**

All dimensions are in mm

**2 Wiring**

Remove all four screws (and save in a safe place) in both cable clamps and open cover. Snap off the cable entry knockout where required.

Wire supply in as below

- 3 - Dali (if required)
- N - Neutral (Blue)
- ⊕ - Earth (Green/Yellow)
- 1 - Live (Brown)
- 2 - Dali (if required)

Finally close and secure lid with the four screws previously removed

