

# RXS - Mini





- Product luminaires comply with EN60598 and are suitable for use in normal interior conditions.
- This luminaire has an ambient temperature range of -25°C to 25°C
















Instruction Manual - K943V4 RXS Mini September 2019

## Safe Operation

- 1. Check the rating label for voltage and frequency before connecting this luminaire to the electrical supply.
- 2. Ensure that the mains supply is switched off when working on this luminaire, whether installing or carrying out any other servicing.
- 3. To prevent damage to driver, do not mix with conventional magnetic ballasts on the same electrical circuit.
- 4. Where use in more onerous situations is required, e.g. In part-completed buildings before "drying-out" is completed, or areas where ambient temperatures are outside the normal temperature range, then consult
- 5. If the external flexible cable of this luminaire is damaged, it shall be returned to the manufacturer in order to avoid any hazard.
- 6. The LED in this luminaire shall only be replaced by the manufacturer.
- 7. If the protective cover becomes damaged, the cover must be replaced to ensure the IP rating remains credible.
- 8. The 90 minute fire rating for this luminaire is only appropriate when fitted as follows:

The timber floor has overall nominal dimensions of 4700 mm long by 3000 mm wide and comprises of softwood timber joists at 600 mm centers. The upper surface of the floor comprises nominally 22 mm thick tongue and grooved chipboard flooring.

The floor assembly should be protected on its underside by a direct fixed ceiling, formed from three layers of 12.5 mm plasterboard referenced 'Fireline'.

# Servicing and Disposal

- 1. At commissioning and handing over of installation ensure that a copy of these instructions is presented to the authority responsible for the operation and maintenance of the luminaries.
- 2. Servicing, e.g. cleaning, must only be carried out after the electricity supply has been switched off. It must not be assumed that luminaries with lamps not lit are switched off-always check before servicing.
- 3. Cleaning should be carried out at regular intervals to ensure that dirt does not accumulate to an extent that will impair the thermal safety or optical performance of the luminaire. Regular cleaning will also ensure that the optical performance of the luminaries is maintained.
- 4. Avoid touching the LED array surface. To clean Blow surface with either dry air or nitrogen gas.
- 5. At the end of life the luminaire is classed as WEEE under directive 2002/96/EC and should be disposed of in accordance with local legislation.

### Luminaire Cleaning









#### End of Life and Components Disposal









Wheatley Hall Road, Doncaster, South Yorkshire, DN2 4NB

Sales T: +44 (0)1302 303303 F: +44 (0)1302 367155 E: sales@cooper-ls.com

General +44 (0)1302 321541 +44 (0)1302 303220

technical@cooper-ls.com

International Sales +44 (0)1302 303250 +44 (0)1302 303251

export@cooper-ls.com

K943V4